

Hauppauge!

4860 MotherBoard Reference Manual

Revision 1.7 May 25, 1991
Copyright 1989, 1990

Hauppauge Computer Works, Inc.
91 Cabot Court
Hauppauge, NY 11788 U.S.A.
Telephone: 516-434-1600
Fax: 516-434-3198

Table of Contents

4860 MotherBoard Reference Manual

Revision 1.7 May 25, 1991 i-1

Installing the 4860 MotherBoard

A quick guide to first-time installation.....	1-1
Run the BIOS Setup program	1-2
Run the EISA Configuration Utility	1-3
Installing i860/APX with the EISA 1.00 (and above) BIOS ..	1-4
Setting the memory size of APX	1-5
Installing the PS/2 style mouse cable	1-5

Guide to jumpers and connectors

PS8 Power supply connection	2-1
PS9 Power supply connection	2-1
PS10 Auxiliary power connection	2-1
J19 Speaker output connector.....	2-1
J9 Reset switch connector	2-1
J11 486 Turbo connector	2-2
J21 External CMOS battery connector.....	2-2
J23 PS/2 compatible mouse interface connector	2-2
J1, J3-J8 EISA 8/16 bit connectors	2-2
J2 ISA compatible 8-bit connector	2-2
J10 64-Bit expansion connector.....	2-2
J20 Keylock/Power LED connector	2-2
J22 DIN-5 Keyboard connector.....	2-3
JP1 i860 timer interrupt jumper	2-3
JP3 Mouse Interrupt (IRQ12) jumper.....	2-3
JP11 2x4 Keyboard configuration header	2-3
JP12 Future i860 mode support	2-3
JP13 Delayed ADS jumper.....	2-3
JP14 25/33MHz Jumper	2-3
JP15 Turbocache Module write protect	2-3
JP2 ... Turbo Cache module	2-3
SW1 ... Monitor select/Burn-in test jumper	2-3
Parallel I/O port jumpers and connector.....	2-4
JP8 Parallel port address select jumper	2-4
JP9 Parallel port interrupt enable jumper.....	2-4

J15	Parallel port connector	2-4
Serial I/O	port jumpers and connectors.....	2-5
JP4	Serial port A address select jumper.....	2-5
JP5	Serial port A interrupt enable jumper.....	2-5
JP6	Serial port B address select jumper.....	2-5
JP7	Serial Port B interrupt enable jumper.....	2-5
J13 , J14	COM1/3 and COM2/4 connectors.....	2-5
4860 MotherBoard	Revision C changes:.....	2-6
JP18 64-bit slot write select	2-6
JP16 Reserved	2-6
JP17 Reserved	2-6
JP10 No longer needed	2-6

Adding additional memory

4860 EISA MotherBoard Diagrams

4860 MotherBoard	Block Diagram	4-1
4860 EISA MotherBoard	layout	4-2
486 /860 Processor	orientations, SIMM connectors	4-3
Mouse connector.....		4-4
Jumper locations		4-5

EISA Configuration Utility

Trademark Information	5-1
Introduction to the EISA Configuration Utility.....	5-1
Command Reference.....	5-4
Using the main menu	5-4
Using the submenus.....	5-4
Using dialogue boxes	5-6
Using screens	5-7
Getting help	5-7
Main Menu Selections.....	5-8
Learn about configuring your computer	5-8
Configure computer	5-8
Copy configuration (CFG) files	5-8
Configure computer - basic method	5-8
Configure computer - advanced method	5-9
Return to main menu.....	5-12
Set date and time	5-12
Exit from this utility	5-12
Starting the Configuration Utility from a fixed disk.....	5-13

Installing the Utility on a Fixed Disk	5-13
Starting the Utility	5-13
Starting Configure Computer selection from a fixed disk	5-14

i860/APX Attached Processor Executive

Overview	6-1
Installing i860/APX-DOS	6-2
Installing 860/APX under UNIX V	6-3
Programs included with i860/APX.....	6-6
i860 development tools.....	6-7
Compilers.....	6-7
Other i860 tools.....	6-7
Discount coupons for compilers.....	6-7
Portland Group discount coupon	6-8

Using VGA display adapters from the i860

Housekeeping: Initialization and Termination	7-1
VGA Library Functions.....	7-2
Global Variables	7-4
Direct Access to Video RAM	7-4

Using the i860 Assembler, Linker and Debugger

Running the i860 Assembler.....	8-1
Running the i860 Linker	8-2
Executing an i860 program and using the i860 Debugger ..	8-5
i860 Debugger Commands.....	8-6
i860 processor registers	8-7
Source code debug statements	8-8
Debugger restrictions.....	8-9

4860 Programmers Reference

I/O Port Summary (ISA/EISA)	9-1
I/O Port Summary (EISA ONLY)	9-2
486 Processor Memory Map	9-2
860 Processor Memory Map	9-2
4860 Frame Buffer Memory Map	9-3
4860 MotherBoard Configuration Register	9-3
Mapping RAM.....	9-4
860 Processor Configuration Register	9-6
860 Processor Interrupt Controller	9-7
Master/NON-Master EISA I/O Slots	9-8

EISA Slot Addresses.....	9-8
Keyboard Controller Input Port.....	9-9
486 Attention Interrupt.....	9-9
860 Attention Interrupt.....	9-10
486 BIOS Special Functions	9-10
860 BIOS Functions.....	9-10

Heartbeat demo

Frame Buffer Demo

Installing the 4860 MotherBoard

A quick guide to first-time installation

Note: When using the EISA BIOS version 1.00 and above, the Power-On self test program will display the message "Slot 00 error: .." during the first-time installation. This message can be ignored, because it alerts us to the fact that the EISA configuration has not yet been set.

Also, note that the BIOS Setup program uses the cursor keypad and the +- keys to move through the BIOS Setup and to set the BIOS options.

Step 1 - Install the 4860 MotherBoard, connect the power cables, the keyboard, speaker, reset connector, and install just the video adapter. The board as shipped from the factory has been jumpered and tested with both ISA and EISA disk controllers and the MotherBoard's serial and parallel ports have also been tested. The only jumper that might need to be changed is the **monitor type** jumper. The factory setting is color. It needs to be changed when using a monochrome monitor. The chapter entitled "Guide to Jumpers, .." describes the 4860 MotherBoard jumpers.

Step 2 - Turn on the power, and look for the Power-On self test messages. A CMOS RAM error message, and several other error messages will appear:

PRESS F1 TO CONTINUE OR CTRL-ALT-ESC TO ENTER SETUP

This is normal since the BIOS and the EISA configurations have not yet been set. One common problem is the "Configuration error" message which appears if the **monitor type** has not been

set correctly. Check the BIOS Setup program or the 4860 MotherBoard **monitor type** jumper.

Run the BIOS Setup program

Step 3 - Run **Setup** by typing Control-Alt-ESC (at the same time). Set the time, date (remember to use the + - keys) and floppy diskette types. Check to see that all of the memory that has been installed has been detected. As an example, on a 4MByte system the following configuration will be seen:

Base memory:	640K
Extended memory:	3072K
Expanded memory:	0K
Other memory:	384K
Total:	4096K

If using an MFM or IDE disk drive, set the hard **drive type** to the correct value.

If you are using an ESDI controller, set **drive type** to 1 or 2 (check with the disk controller manufacturer for the correct entry).

If using a SCSI controller, normally the **drive type** should be set to NONE. But be aware that some SCSI controllers will require the **drive type** to be set to 1.

If your MFM or IDE controller does not have a drive type that matches its parameters, there are two configurable drive types, 48 and 49, where you can set custom parameters. After entering either 48 or 49, use the right arrow key to get to the different parameters for your hard disk drive. Remember, since this is a custom hard disk drive type, write these parameters on a label that can be placed on the outside of your PC just in case the CMOS RAM is erased.

Hit the "PgDn" key (page down) to go to the next BIOS Setup screen. Here you can enable or disable the CPU cache, the BIOS cache and the Video cache. We recommend that all items be **ENABLED**. You can experiment with the effects on

performance by disabling the settings later on, but for now enable everything.

Leave the Default speed setting at **HIGH** and the Slow speed at **FAST**.

Hit **F10,F5** to save the CMOS Setup and to exit the Setup program.

Step 4 - Turn the power off, and install the floppy disk controller (or combination floppy/hard disk controller). Connect the cables to the floppies and make sure the power is also connected to the floppies.

Install a DOS disk (DOS 3.3 recommended) and turn the power back on. The Power-On self test program might display an "Error initializing hard disk 0" since the hard disk is not connected. This is o.k. Boot DOS from the floppy disk.

Run the EISA Configuration Utility

Step 5 - Now that DOS has been booted from the floppy, the EISA configuration must be set. The Hauppauge 4860 MotherBoard is provided with an EISA Configuration diskette that contains a program called **CF**. This diskette must be put in the floppy disk drive and the program **CF** should be run.

In systems without an EISA disk controller, the key sequence to set the EISA configuration is simple: **enter, enter,F10,S,X** and then choose **Save Configuration and Exit**. This will save the minimum EISA information required for use with non-EISA disk controllers.

In systems with an EISA I/O controller, before the **CF** program is run, the configuration program provided by the controller vendor must be copied onto the the Hauppauge EISA Configuration diskette. Then run **CF**, following instructions from your I/O controller manual. To save the EISA configuration once it has been set in the **CF** program, type **F10,S,X** and then choose **Save Configuration and Exit**.

Step 6 - Now that the BIOS has been set, and the EISA configuration has been saved in both the CMOS RAM and the diskette, you can connect the hard disk drive and boot.

If the battery that holds the CMOS RAM ever drains while the power is turned off, you must run the BIOS Setup, then run **CF**, using the old parameters saved on the diskette.

If you add or remove EISA I/O cards from the system, you need to run **CF** to modify the system configuration.

Installing i860/APX with the EISA 1.00 (and above) BIOS

When installing i860/APX, there are two extra steps in the setup. These steps partition the memory system between the i860 and the 486 processor.

The memory partitioning puts a gap in the memory space between the i860 and the 486. This gap is necessary so that 486 programs such as UNIX or OS/2 do not try to "grab" all of system memory for themselves.

To partition the memory, run the program **CFG4860**, which can be found on the EISA Configuration diskette. On the second screen, move the cursor with the down arrow key to the i860 memory option. Hit **8M** (to select 8MBytes of memory for the i860; from 4M to 16MBytes can be selected for the i860), and then down arrow once more. Now hit **F10**, **F5** to save this memory configuration.

Once the memory configuration is saved, it is necessary to do a hard reset (push the reset button or turn off the computer). After the hard reset, during the Power-On-Self-Test a message will appear stating **MEMORY SIZE ERROR**. This is o.k. since we have just changed the amount of memory seen by the 486 processor. Just hit **F1** to remove this message.

To check the memory configuration, run **INFO4860** (also on the EISA Configuration diskette), and observe the i860 Dedicated Memory setting. Due to a bug in **INFO4860**, please ignore the

message: i860 Not Present.

Note: It is not necessary to change the i860 memory size in the program "CF" once this has been set using CFG4860. Though you will find an entry for i860 memory size in CF, it is not necessary to change this entry.

Setting the memory size of APX

Note: The following procedure is necessary only for i860/APX versions 1.7 and below. With version 1.8, the memory size is automatically configured.

i860/APX has the memory configuration set during the APX installation. If any other memory configuration is used, the APX driver in UNIX must be told of this new configuration. There is a file called "kernel.cfg" which has been installed during the APX installation procedure which must be modified. The file is typically found in the `/usr/apx5/gen/src/ker860` directory under UNIX, and the `/usr/apx5/ker860` directory in i860/APX-DOS.

The two entries that need to be changed are:

ev_memory_size = 8

host_memory_size = 8

The 8 is an example showing 8MBytes. For example, if the 486 memory is 16MBytes, then change **host_memory_size** to 16. If the i860 memory size changes, then change the **ev_memory_size** entry. Note that this must be done after **installapx** is run.

Installing the PS/2 style mouse cable

The cable for the PS/2 style mouse connector consists of two pieces:

- Cable: 10 pin header to female DB-9
- Adaptor: DB-9 male to PS/2 style DIN

The 10 pin header is installed on the 4860 MotherBoard in con-

ector J23 (located near the Power Connector). See diagram 4.3 in the 4860 Reference manual for its location. Pin 1 of the cable is near the red stripe. **The mouse will not work if the cable is plugged in backwards.** Make sure the red stripe is towards pin 1 of J23.

The DB-9 female connector on the 10 pin cable is normally mounted on a bracket of the system chassis. The DB-9 to PS/2 adaptor is then attached to DB-9 female connector from the outside of the chassis.

Guide to jumpers and connectors

Note - * indicates default setting

- PS8 Power supply connection**
1 = /PWRGOOD from power supply
2 = +5 Volts
3 = +12 Volts
4 = -12 Volts
5,6 = GND
- PS9 Power supply connection**
1,2 = GND
3 = -5 Volts
4,5,6 = +5 Volts
- PS10 Auxiliary power connection**
Connects to PC Power & Cooling Model TURBO-450 power supply. Key is at pin 2.
1,2,3 = +5 Volts
4,5,6 = GND
- J19 Speaker output connector**
1 = +SPKR
2 = N.C.
3 = -SPKR
4 = +5 volts
- J9 Reset switch connector**
*Open = run
Short = reset

- J11 486 Turbo connector**
1 = VCC
2 = Turbo LED output (sink)
3,4,5 = N.C.
6 = TURBO Control
7 = GND
- J21 External CMOS battery connector**
1 = +VBB (minimum +4.5v, max 6v)
2 = N.C.
3, 4 = -VBB (normally ground)
- J23 PS/2 compatible mouse interface connector**
Note: Requires special cable. See diagram in Chapter 3.
1 = Clock
2 = Data
4 = Signal Ground
5 = +5 Volts
3,6,7,8,9,10 = Shield Ground
- J1, J3-J8 EISA 8/16 bit connectors**
(J1, J3-J6 and J8 are EISA MASTER capable,
J7 will not allow EISA bus masters)
- J2 ISA compatible 8-bit connector**
- J10 64-Bit expansion connector**
(to be supplied in a future revision of this manual)
- J20 Keylock/Power LED connector**
1 = GND
2 = KEYLOCK
3 = GND
4 = [KEY]
5 = +5 Volts

- J22 DIN-5 Keyboard connector**
 1 = CLOCK 4 = GND
 2 = DATA 5 = +5 Volts
 3 = N.C.
- JP1 i860 timer interrupt jumper**
 *2-3 (61.7911 msec)
 1-2 (30.8955 msec)
- JP3 Mouse Interrupt (IRQ12) jumper**
 *1-2 = No interrupt generated
 2-3 = Enable mouse interrupt
- JP11 2x4 Keyboard configuration header**
 Do not change unless instructed for a Keyboard BIOS upgrade
- JP12 Future i860 mode support**
 *Closed = DO NOT INSTALL
- JP13 Delayed ADS jumper**
 *2-3 = DO NOT CHANGE
- JP14 25/33MHz Jumper**
 Short = 25MHz
 Open = 33MHz
- JP15 Turbocache Module write protect**
 Open = write protected item cached by 486 & Turbocache
 Short = write protected item cached by Turbocache only
- JP2 Turbo Cache module**
 *In = Turbo cache not installed
 Out = Turbo cache installed
- SW1 Monitor select/Burn-in test jumper**
 *Open selects Monochrome
 1-2 selects burn-in test
 2-3 selects color monitor

Parallel I/O port jumpers and connector

JP8 Parallel port address select jumper

1-2 = LPT1 (port 03BCh)

*2-3 = LPT2 (port 0378h)

JP9 Parallel port interrupt enable jumper

*Short = LPT1/2 generates IRQ7

Open = No interrupt generated

J15 Parallel port connector

NOTE: Cable straight from 2x13 header to DB25 connector

NOTE: Pin 1 is LEFT-BOTTOM and goes to pin 1 of DB25

1 = /STB	2 = /AFD
3 = D0	4 = /ERR
5 = D1	6 = /INIT
7 = D2	8 = /SLIN
9 = D3	10 = GND
11 = D4	12 = GND
13 = D5	14 = GND
15 = D6	16 = GND
17 = D7	18 = GND
19 = /ACK	20 = GND
21 = BUSY	22 = GND
23 = PE	24 = GND
25 = SLCT	26 = GND (not used on DB25 connector)

Serial I/O port jumpers and connectors

- JP4 Serial port A address select jumper**
*1-2 = Port A is COM1
2-3 = Port A is COM3
- JP5 Serial port A interrupt enable jumper**
*Short = COM1/3 generate IRQ4
Open = No interrupt generated
- JP6 Serial port B address select jumper**
*1-2 = Port B is COM2
2-3 = Port B is COM4
- JP7 Serial Port B interrupt enable jumper**
*Short = COM2/4 generate IRQ3
Open = No interrupt generated

J13 , J14 COM1/3 and COM2/4 connectors

NOTE: Cable straight from 2x5 header to DB9 connector

NOTE: Pin 1 is LEFT-BOTTOM and goes to pin 1 of DB9

1 = DCD(I)	2 = DSR(I)
3 = RxD(I)	4 = RTS(O)
5 = TxD(O)	6 = CTS(I)
7 = DTR(O)	8 = RI(I)
9 = GND	10 = GND (not used on DB9 connector)

4860 MotherBoard Revision C changes:

JP18 64-bit slot write select

1-2 CPUWR#

* 2-3 BCPUWR#

JP16 Reserved

Must be left open

JP17 Reserved

Must be left open

JP10 No longer needed

Adding additional memory

The 4860 EISA MotherBoard requires the RAM to be loaded in **pairs** of 36-bit SIMMs. The SIMM modules can be 2MByte, 4MByte or 8MBytes per module. The modules may be mixed and matched as long as they are paired.

We recommend using 70nsec SIMM modules for the 4860-33MHz MotherBoard. Some (but not all) qualified modules are:

2 MByte:

Toshiba THM365120S-70

Micron MT8C36512DM-7

Samsung KMM536512A-7

4 Mbyte:

Toshiba THM361020S-70

OKI MSC2355-70YS12

NEC MC421000A36BH70

8 MByte:

Toshiba THM362020S-70

OKI MSC2356-70YS18

NEC MC422000A36BH70

In the default BIOS configuration, RAM is populated in sockets **U20** and **U24**. RAM grows upwards from this point using sockets **U21** and **U25**, then **U22** and **U26**, and finally **U23** and **U27**. A sample configuration might be:

U20, U24	512K x 36 (2MB SIMM's)	4MBytes
U21, U25	1M x 36 (4MB SIMM's)	8MBytes
U22, U26	512K x 36 (2MB SIMM's)	4MBytes
U23, U27	2M x 36 (8MB SIMM's)	16MBytes


This configuration contains 32 Megabytes of memory. Any (or all) of this memory can be allocated to either the 486 or 860 by running a simple re-mapping program (see Chapter 1 for instructions on running **CFG4860**).

The following chart shows some sample memory configurations. Three configurations are shown; 4MB, 16MB and 32MB:


Socket	4MBytes	16MBytes	32 MBytes
U20	2MB SIMM	4MB SIMM	2MB SIMM
U21		4MB SIMM	4MB SIMM
U22			2MB SIMM
U23			8MB SIMM
U24	2MB SIMM	4MB SIMM	2MB SIMM
U25		4MB SIMM	4MB SIMM
U26			2MB SIMM
U27			8MB SIMM

4860 EISA MotherBoard Diagrams


4860 MotherBoard Block Diagram




4860 EISA MotherBoard layout



486 /860 Processor orientations, SIMM connectors




Mouse connector



Mouse Connector
(As seen from back
of computer)

Jumper locations



EISA Configuration Utility

Trademark Information

Configuration Utility User's Guide Version 1.10. Micro Computer Systems, Inc., Hauppauge Computer Works, Inc.

NOTICE: The information in this guide is subject to change without notice.

NEITHER MICRO COMPUTER SYSTEMS, INC. OR HAUPPAUGE COMPUTER WORKS, INC. SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL OMISSIONS MADE HEREIN; NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS MATERIAL.

This guide contains information protected by copyright. No part of this guide may be photocopied or reproduced in any form without prior written consent from Micro Computer Systems, Inc.

Copyright 1989, 1990 Micro Computer Systems, Inc. All Rights Reserved.

Copyright 1990 Hauppauge Computer Works, Inc. All Rights Reserved

The software described in this guide is furnished under a license agreement and may be used or copied only in accordance with the terms of the agreement.

MS-DOS is a registered trademark of Microsoft Corporation

Introduction to the EISA Configuration Utility

The Extended Industry Standard Architecture Configuration Utility is a software utility for the configuration of EISA com-

puters. Delivered with all EISA machines, the EISA Configuration Utility automatically generates conflict-free configuration information for the system, and provides information to the user for the correct setting of switches and jumpers on older-design ISA cards.

The Problem

In the ISA architecture, one of the biggest challenges faced by a user is configuring the computer. The computer must be configured when it is initially set up and any time hardware is added to or removed from the system. This often requires reading several manuals to find the information needed to correctly set switches and jumpers as well as learning new concepts such as I/O addresses and interrupt levels. Once the user has configured the computer, the only way to know if it is configured correctly is to plug all the boards in and see if everything works. If not, there is usually little to assist the user in resolving the problem.

The Solution

In the new EISA architecture, option boards are designed without switches or jumpers. Configuration is achieved through a series of initialization commands that are stored in nonvolatile memory. The EISA Configuration Utility determines the configuration, creates the initialization commands, and ensures that the configuration is correct. If a conflict free configuration is not possible, the user is notified immediately.

At system power-up time, the EISA system ROM downloads system initialization information from nonvolatile memory to the slot-specific I/O addresses for each EISA board to declare system resource use and other manufacturer-defined options. For EISA boards, this port initialization process is automated, and it replaces the switch and jumper setting method used for ISA boards.

One advantage of EISA is the ability to accept existing ISA boards. The expansion bus of an EISA computer is defined to be a superset of the Industry Standard Architecture and main-

tains full upward compatibility for option boards originally designed for 8 and 16 bit ISA computers. Boards designed for the ISA architecture containing switches and jumpers can coexist with software programmable boards in an EISA system. In addition to generating initialization information for EISA boards, the EISA Configuration Utility is able to determine the switch settings for any ISA board in a system if a corresponding ISA CFG file is supplied.

Configuration (CFG) and Extension (OVL) Files

Each option board in an EISA system has a corresponding configuration file (CFG) that describes the characteristics and the required system resources of that board. The EISA Configuration Utility uses the information from the CFG files to create a conflict-free configuration.

Despite the extensive flexibility of the format of the CFG file, there may be times when the Configuration Utility can not support all possible configuration options. Therefore, executable code in the form of an OVL file can be integrated into the Configuration Utility's processing. This allows further customization of the configuration process for any unusual board specific needs, such as determining system equipment, fixed disks, coprocessors, floppy drives, system passwords, and other special devices.

System Configuration Information Files (SCI)

The EISA Configuration Utility has the ability to create configuration information files which can later be used on another computer. These files are named with the SCI extension. In addition, the SYSTEM.SCI file is maintained by the Configuration Utility as a backup for the computer's EISA nonvolatile memory.

When the Configuration Utility is first executed, it determines if the nonvolatile memory information is valid. If the nonvolatile memory information is invalid, the configuration may be restored by loading an SCI file from the configuration disk or by manually selecting CFG files and assigning them to slots.

Starting the utility

This utility runs on any ISA or EISA computer using MS-DOS version 3.2 or later. A minimum of 640 Kbytes of memory and a 1.2 megabyte diskette drive are required. A mouse is also recommended to move the cursor and to select options within the utility.

To start the utility, insert the System Configuration diskette in drive A. Then, turn on your computer. If your computer is already on, hold down [Ctrl] and [Alt], and press [Del] at the same time. A logo screen will be displayed. Press any key to display a welcome screen. Press [Enter] to leave the welcome screen and display the main menu. Refer to Chapter 2, "Command Reference," for instructions on using the menu and a description of the menu selections.

Command Reference

Using the main menu

There are two ways to choose a menu selection from the main menu: using the keyboard and using a mouse. To choose a menu selection using the keyboard, use the up and down arrow keys to position the cursor on the desired menu selection and press [Enter].

To choose a menu selection using a mouse, position the mouse cursor over the desired selection on the menu and click the left button on the mouse.

Using the submenus

Five pull-down menus can be used when you choose the Configure Computer - Advanced Method selection (for menu options see MAIN MENU SELECTIONS section in this guide). These menus are listed in the menu bar at the top of the screen. There are three ways to use the pull-down menus:

Using the keyboard

To make menu selections using the keyboard, follow these

steps:

1. Press the [F10] key to place the cursor on the menu bar.
2. Use the [left arrow] and [right arrow] keys to position the cursor on the desired pull-down menu name.
3. Press the [Enter] key to display the pull-down menu.
4. Use the [up arrow] and [down arrow] keys to position the cursor on the desired pull-down menu item.
5. Press the [Enter] key to execute the pull-down menu item. If the menu item ends in an ellipsis (...), a dialogue box will be displayed to prompt you for further information; otherwise, the menu item will be executed directly.

Using enhanced letters

Each pull-down menu listed on the menu bar and each item on the pull-down menus have a single enhanced letter. To make a selection using enhanced letters, follow these steps:

1. Press and hold down the [Alt] key while pressing the enhanced letter for the desired pull-down menu. The pull-down menu is displayed.
2. Press the enhanced letter that corresponds to the desired menu item to execute the menu item. If the menu item ends in an ellipsis (...), a dialogue box will be displayed to prompt you for further information; otherwise, the menu item will be executed directly.

Using a mouse

To make menu selections using a mouse, follow these steps:

1. Place the mouse cursor over the desired pull-down menu name on the menu bar and click the left button on the mouse. The pull-down menu is displayed.

2. Place the mouse cursor over the desired pull-down menu item and click the left button on the mouse to execute the menu item. If the menu item ends in an ellipsis (...), a dialogue box will be displayed to prompt you for further information; otherwise, the menu item will be executed directly.

Using dialogue boxes

When you select a menu item that ends in an ellipsis (...), a dialogue box will be displayed to prompt you for further information. There are two ways to use a dialogue box:

Using dialogue boxes from the keyboard

To move within a dialogue box using the keyboard, follow these guidelines:

1. Press [Tab] to move to the next field or area.
2. Press [Shift + Tab] to move to the previous field or area.
3. Use the arrow keys to move between items in a list.
4. Press the space bar to turn a check box on or off.
5. Press the [Enter] key to select.
6. Press [Esc] to cancel the dialogue box.

Using dialogue boxes with a mouse

To move within a dialogue box with a mouse, follow these steps:

1. Place the mouse cursor over the desired choice in the dialogue box and click the left button.
2. Place the mouse cursor on a check box and click the left button to turn the check box on and off.
3. Place the mouse cursor on a button and click the left mouse button.

Using screens

When your configuration is displayed in an overview or a detailed view, use the following methods to move the cursor:

Using the keyboard

To move the cursor on the screen using the keyboard, follow these guidelines:

1. Press [Tab] to move to the next option.
2. Press [Shift + Tab] to move to the previous option.
3. Press [Ctrl + Home] to move to the beginning of the information.
4. Press [Page Down] to move down one screen.
5. Press the [down arrow] key to move down one line.
6. Press [Page Up] to move up one screen.
7. Press the [up arrow] key to move up one line.
8. Press [Ctrl + End] to move to the end of the information.

Using a mouse

To move the cursor on the screen using a mouse, follow these guidelines:

1. Place the mouse cursor over the desired area on the screen and click the left button.
2. If a scroll bar is displayed on the right side of the screen, place the mouse cursor over the arrow symbol at the top or bottom of the scroll bar and press the left button.

Getting help

An information line is displayed on the last line of your screen. This line contains a list of the keys you can use.

You can get help about a selection on a menu or any object on a screen by pressing the [F1] key while your cursor is on the selection or object. You can also display help from the help topics index by selecting Help topics from the Help pull-down menu or by pressing [Shift + F1].

For a complete list of key combinations, press [Shift + F1] to display the help topics index. Then use the arrow keys to select "Using the keyboard" and press [Enter].

Main Menu Selections

Learn about configuring your computer

This selection will display an overview of how to use this utility to configure your computer.

Configure computer

When you choose this selection, a menu is displayed with the following selections:

Copy configuration (CFG) files

Configure computer - basic method

Configure computer - advanced method

Return to the main menu

Copy configuration (CFG) files

This selection copies configuration (CFG) files from an OPTION CONFIGURATION diskette or the Configuration File Library to your System Configuration diskette. You need to copy a CFG file for each board or option you plan to install BEFORE you configure your computer.

Configure computer - basic method

This selection will guide you through the procedure for adding boards and options to your computer. When you choose this

selection, a graphical overview of the boards and options installed in your computer is displayed on the screen. When there are no resource conflicts, the configuration information is saved in a system configuration information (SCI) file. If you need to change functions, edit resources or perform advanced tasks, use the advanced method.

Before you return to the main menu, a list of the switch, jumper, and software settings which you need to change for ISA boards can be displayed. Either write them down or print them if you have a parallel printer attached to your computer. If you do not have a CFG file for an option or board you want to install, use the instructions provided with the option to install it.

Configure computer - advanced method

When you choose this selection, a graphical overview of the boards and options installed in your computer is displayed on the screen. A menu bar is displayed at the top of the screen, which you use to access pull-down menus.

This selection allows you to enter configuration information about your computer through the use of pull-down menus (see MENU BAR SELECTIONS for pull down menu option functions). As you enter information, the entries are verified (when Auto Verify is on (default)). If any resource conflicts are found, you are allowed to correct the errors by changing function and resource choices. When there are no resource conflicts, the configuration information is saved in a system configuration information (SCI) file.

Menu Bar Selections

Menu Bar

SelectionPull-Down Menu

SelectionFunction

SystemNew Creates a new configuration and system configuration information (SCI) file for a computer (available in non-target

modeling mode only).

Open Opens an existing system configuration information(SCI) file for editing.

Save As Makes a backup copy of the current configuration choices in a specified system configuration (SCI) file.

Print Prints configuration information about the current option or the entire configuration on a printer.

Verify Verifies that the computer is correctly configured (the configuration is free of system resource conflicts.)

Exit Prompts to either view the settings of the boards and options, save the configuration and exit, or exit without saving any changes. If the configuration has changed and is saved, the computer will reboot instead of exiting to the menu.

EditAdd Adds a selected board or option to the current configuration.

Move Selects the current board and moves it to a selected available slot.

Remove Selects the current board and removes it from the current configuration.

Change Function Selects the current function and allows you to change the function choice. Only available when the detailed view is active.

Change Resource Selects the current function and allows you to change the system resources for the function. Only available when the detailed view is active.

Revert to Saved Sets all choices for the current board or the entire configuration to the last saved choices.

Reset to Defaults Sets all choices for the current board or the

entire configuration to the manufacturer's default choices.

Lock Secures all choices for the current board or the entire configuration to the current selections.

Unlock Unlocks all choices for the current board or the entire configuration.

ViewOverview When selected, displays a general overview of the configuration.

Detailed by Slot When selected, displays a detailed view of the configuration sorted by slot.

Detailed by Type When selected, displays a detailed view of the configuration sorted by type of function.

Switch and Jumper Settings Selects the current board or option and displays information about its switches and jumpers.

Software Parameters Selects the current board or option and displays information about software drivers.

Connections Selects the current board or option and displays information about its external cable connections.

Board Specifications Selects the current board or option and displays information about identification and physical characteristics.

Resources Selects the current board or function and displays system resource summary information.

SettingsAuto Verify When selected, your computer's configuration is checked for resource conflicts each time you change the configuration. Selecting Auto Verify turns Manual Verify off.

Manual Verify When selected, your computer's configuration is not checked for resource conflicts. You must select Verify from the System pull-down menu to check your computer's configura-

tion. Selecting Manual Verify turns Auto Verify off.

HelpHelp Topics Displays an index of help topics which can be displayed on your screen.

Help Displays help information about the currently selected board, option, or function. This menu item performs the same function as pressing the [F1] key.

How to Use Keys Displays a list of the key sequences which can be used.

How to Use Help Displays information about using help.

Copyright Information Displays copyright information about this utility.

Before you return to the main menu, a list of the switch, jumper, and software settings, which you need to change for ISA boards, can be displayed. Either write them down or print them if you have a parallel printer attached to your computer. If you do not have a CFG file for an option or board you want to install, use the instructions provided with the option to install it.

Return to main menu

This selection will return you to the main menu.

Set date and time

This selection allows you to set your computer's date and time. Once you set the date and time, your computer will keep track of it, even if the power is turned off.

Exit from this utility

This selection exits the utility. The system will reboot. If you do not have an operating system installed on your fixed disk, replace the System Configuration diskette in the diskette drive with your operating system diskette.

Starting the Configuration Utility from a fixed disk

It is recommended that you start this utility from the System Configuration diskette. However, if you have MS-DOS installed on your fixed disk, you can start the utility from your fixed disk. Starting the utility from your fixed disk allows you to customize the utility through the use of command line parameters.

Installing the Utility on a Fixed Disk

Before you can start the utility from your fixed disk, you must copy the utility files to your fixed disk. To copy the files, insert the System Configuration diskette in drive A and enter:

```
COPY A:*. * [d:][path]
```

where:

d: is the fixed drive that will contain the utility files

path is the path on the fixed drive that will contain the utility files

Starting the Utility

To run the utility, type the following command followed by [Enter]. Note that items in brackets are optional and only the information within the brackets is entered.

```
[d:][path]SD [/A] [/B] [/H] [/K] [/M]
```

where:

d: is the drive which contains the utility files

path is the path to the utility files

/A Expanded mode. Provides an expanded set of menus with additional functionality. This mode may also be activated by pressing CTRL-A instead of [Enter] when the "Welcome" screen is displayed.

/B BIOS video mode. This parameter causes all screens to be displayed using BIOS Int 10h calls. This parameter should be used on computers with non-standard displays. The default mode is to write directly to video memory.

/H High resolution display. If you have an EGA monitor, the utility will be displayed in 43-line mode. If you have a VGA monitor, the utility will be displayed in 50-line mode. When this parameter is not used, 25 lines will be displayed on your screen.

/K Keyboard only mode. If this parameter is used, the computer will not support the use of a mouse device even if one is present. The default is to support a mouse if its driver is loaded.

/M Monochrome display mode. Color not used.

When the utility begins, a logo screen will be displayed. Press any key to display a "Welcome" screen. Press[Enter] to leave the "Welcome" screen and display the main menu. Refer to "Command Reference," for instructions on using the menu and a description of the menu selections.

Starting Configure Computer selection from a fixed disk

You can bypass the main menu and start the Configure Computer selection directly from MS-DOS. This allows you to use command line parameters to customize the operation of the utility. You must have MS-DOS and this utility installed on your fixed disk.

Use the following format to type the command that starts this selection from MS-DOS. Note that items in brackets are optional and only the information within the brackets is entered.

[d:][path]CF [/B] [/E] [/F] [/H] [/K] [/M] [/N] [/T]

where:

d: is the drive which contains the utility files

path is the path to the utility files

/B BIOS video mode. This parameter causes all screens to be displayed using BIOS Int 10h calls. This parameter should be used on computers with non-standard displays. The default mode is to write directly to video memory.

/E Easy configuration operation. Starts the utility in Basic Method.

/F Fast configuration operation. This is the automatic configuration mode. The utility will determine the boards and options and configure the system without user assistance.

/H High resolution display. If you have an EGA monitor, the utility will be displayed in 43-line mode. If you have a VGA monitor, the utility will be displayed in 50-line mode. When this parameter is not used, 25 lines will be displayed on your screen.

/M Monochrome display.

/K Keyboard only mode. If this parameter is used, the computer will not support the use of a mouse device even if one is present. The default is to support a mouse if its driver is loaded in memory.

/N Non-target modeling mode. This parameter runs the utility in non-target modeling mode. When you run this utility, the configuration which is stored in the system configuration information (SCI) file named SYSTEM.SCI is displayed. When the configuration is saved, it is normally saved to the SYSTEM.SCI file. However, with non-target modeling mode, you can create an SCI file for a computer other than the one on which you are running the utility, create multiple SCI files, and create one SCI file for multiple computers.

/T Detailed view by slot. This parameter causes the default view to be detailed by slot instead of overview.

i860/APX Attached Processor Executive

Overview

i860/APX is the operating system to support i860 based applications. It requires a host operating system such as UNIX or DOS to run on the 486 processor while the i860/APX Executive runs at the same time on the i860 processor.

i860/APX lets the 486 host operating system perform all system I/O, including reading and writing disk files and displaying data on the video screen. The i860 RISC processor is free to run its programs without having to be concerned with the details of the host operating system. This means that programs developed for the i860 on one operating system (DOS for example) can be run on any of the other APX supported operating systems (SCO UNIX for example), **without modification or recompiling!** This is called "binary portability".

Once i860/APX is loaded and is running on the i860 processor, standard C and Fortran programs can be compiled with i860 compilers and executed using i860 tools. A reference to some of the available i860 tools is at the end of this chapter.

System support requirements to load i860/APX are:

- Hauppauge 4860 MotherBoard with both 486 and 860 processors and 4MBytes minimum for the 486 and 4MBytes minimum for the 860.
- For i860/APX-UNIX: ATT UNIX V version 3.2.2, ATT UNIX V version 4.0, Interactive UNIX V version 3.2.2 or SCO Open Desktop ver. 3.2.2 installed on the hard disk
- For i860/APX-DOS: DOS 3.3, 4.01 or 5.0 installed on a hard disk
- 1.2 MByte floppy

See Chapter 1 for configuring the memory system for use with i860/APX. Please read the sections titled **Installing i860/APX with the EISA BIOS** and **Setting the memory size of APX**.

Installing i860/APX-DOS

To install the i860/APX-DOS software from your Hauppauge APX diskette, insert your APX floppy in drive A; and type:

```
mkdir c:\apx5
```

```
xcopy a: c:\apx5\*. * /s
```

i860/APX-DOS is loaded in two parts: a DOS driver which is loaded by CONFIG.SYS, and the i860/APX Executive which can be loaded from the command prompt (c:\).

The DOS driver is called N860.SYS. This driver uses the protected mode of the 486 processor, and so it should be loaded before other protected mode drivers are loaded. Modify your CONFIG.SYS file by adding:

```
device = c:\apx5\N860.SYS
```

The APX system configuration is in the **KER860** subdirectory in a file called **kernel.cfg**. The two parameters that should be modified are **ev_memory_size** (the amount of 860 memory that is configured) and **host_memory_size** (the amount of 486 memory that is configured). Once again, see Chapter 1 for configuring the memory system for use with i860/APX. Please read the sections titled **Installing i860/APX with the EISA BIOS** and **Setting the memory size of APX**.

The i860/APX Executive is loaded by moving to the **c:\apx** directory, and then typing:

```
boot860
```

This needs to be done twice due to a bug in i860/APX. After the i860/APX driver is loaded, check to see if APX is functional

by typing:

```
adm860 -s
```

The correct status should include the number of hours, minutes and seconds that APX has been loaded. To run a simple test program, type:

```
run860 hilbert
```

This demo program does a matrix multiply, and takes about 5 seconds to run. The speed of this complex math program is equivalent to running on the original CRAY 1 supercomputer!

Please note: the i860 program debugger, normally part of in the **run860** command, is currently not functional under i860/APX-DOS.

A separate directory, called `\usr\pgi`, has been setup for the Portland Group i860 compilers. The i860/APX-DOS diskette does not come with these compilers, but the directory is set up with the correct script files to run the Portland Group compilers should you have them. Also, to support the i860 compilers the i860/APX-DOS distribution diskette comes with **TMP** directories. These can be removed if you are not planning to use the i860 compilers.

Installing 860/APX under UNIX V

Once UNIX V has been loaded on the hard disk and can be booted, 860/APX can be loaded from a floppy disk.

After booting the UNIX operating system on the 486 processor, the user must log in as **root**. Make sure the current directory is the root directory and that the 860/APX load floppy is in the 1.2MByte floppy disk drive.

If the primary floppy disk drive is a 1.2MByte floppy disk drive, the following commands will load i860/APX onto the hard disk:

```
# mkdir /apx5
# mount -r /dev/dsk/f05ht /apx5
# /apx5/installapx
# shutdown -g0
```

The shutdown command will allow the re-booting of UNIX so that the 860/APX driver will be loaded. When the system issues the command "Reboot the system now", reboot by hitting CTRL-ALT-DEL. The loading process takes about 15 minutes.

Note: If drive B: is the 1.2MByte floppy, then substitute the following command in the second step:

```
# mount -r /dev/dsk/f15ht /apx5
```

After the installation is complete, all 860/APX programs, utilities and demo programs are put into a directory called:

```
/usr/apx5
```

There are several subdirectories that hold binary files, demo programs and programs needed during the APX installation process.

At this point UNIX will be rebooted and the 860/APX drivers will be loaded. The following message shows that the 860/APX driver has been loaded into the UNIX operating system:

```
i860 Driver Release 1.0 found
```

After logging in as root, the PATH should be set to the /usr/apx5/bin directory by either adding /usr/apx5/bin to your current path, editing the .profile file or by typing:

```
PATH = PATH$:/usr/apx5/bin
```

You can now load 860/APX onto the i860 processor by execut-

ing the following commands:

```
# boot860&
```

```
# boot860&
```

- **Note:** boot860 needs to be run twice on initial powerup. This is due to a bug in 860/APX, which will be fixed in the next release of 860/APX.
- **Note:** the ampersand (&) at the end of boot860 allows UNIX to continue even if the boot860 command fails. If there is a hardware problem, you are still in UNIX and can gracefully shut down UNIX without having to push the reset button.

This loads the Attached Processor Executive on the 4860, and prepares for the execution of i860 programs. If 860/APX does not load at this point, it means the i860 processor is not functioning properly. The reasons for this might be:

- i860 processor was not installed in the Hauppauge 860 MotherBoard, or was not plugged in all the way.
- The SIMM modules for the i860 were not plugged in, or are not functioning properly.

After the 860/APX has been loaded onto the i860, you can check the status of APX by typing:

```
# adm860 -s&
```

To run an i860 program type:

```
# run860 xxx
```

where xxx is the name of a program that has been compiled with an i860 compiler. A demo program called hilbert has been included and can be run by the following command:

```
# run860 /usr/apx5/tests/hilbert
```

To debug this program, the following command can be used. Please refer to the chapter called "i860 Assembler, Linker and Debugger" for a list of debugger commands:

```
# run860 -d /usr/apx5/tests/hilbert
```

To see the source code of this program type:

```
# cat /usr/apx5/tests/hilbert.c
```

There are other programs which have been compiled to run on the i860 processor using a i860C compiler from Metaware. These include hilbert, hil11 and mandel (which requires a VGA adaptor). All of these programs can be found in the directory:

```
/usr/apx5/tests
```

Programs included with i860/APX

boot860: loads the 860/APX Executive into the i860's memory space and then has the i860 Executive run its startup code. Once boot860 has been run, other programs can be loaded into RAM by invoking **run860** for execution by the i860 processor.

adm860: the i860 System Administrator. Shows the status of programs running on the i860, and allows these programs to be shut down.

To see the i860 program status type:

```
adm860 -s&
```

Other options can be found by typing adm860, which will show all options.

run860: loads an i860 program from the disk into the i860's memory space and starts the i860 processor executing it. If the run860 command is followed by **-d**, a debug session is started. If the command line is appended with an ampersand (&), i860 status can be checked by running adm860:

run860 xxx&

adm860 -s&

reset: resets the i860. This program is useful if the i860 program crashes and it is necessary to reset the i860 without resetting the i486 processor.

i860 development tools

Compilers

Metaware: High C i860

- tele: 408-429-6382 fax: 408-429-9273

Green Hills: C-i860, C+ +, Fortran

- tele: 805-965-6044 fax: 805-965-6343

Portland Group: C, Fortran Compiler

- tele: 503-682-2806 fax: 503-682-2637

Other i860 tools

Hauppauge Computer Works, Inc.: i860ASM, i860Linker


Portland Group: Debugger; GUI for X-windows

Profiler/Monitor

Discount coupons for compilers

On the next page are coupons good for discounts on compilers for the i860. They are provided by the vendors of the compilers, and should be redeemed directly with them.

Portland Group discount coupon



The Portland Group

SuperCompilers and Advanced Development Environments

* **CERTIFICATE** *
\$1,000 **\$1,000**

This Certificate entitles the bearer to \$1,000 discount on the price of a Portland Group 1860 Compiler

Hauptpage 4860 Serial Number _____

Name _____
Organization _____
Address _____
Dept _____ Mail Stop _____
City _____ St _____ Zip _____

This certificate is good for a single 1860 compiler and support tool purchase (either Fortran or C with as, ld, & ar) per Hauptpage 4860 board, with UNIX V 3.2 OS. All other discounts and promotions do not apply. Offer expires March 30, 1991

9150 SW Pioneer Court, Suite H, Wilsonville, Oregon 97070

Using VGA display adapters from the i860

The Hauppauge i860VGA Library provides the i860 programmer direct access to VGA graphics capabilities from C programs written under Hauppauge's release of i860/APX-UNIX for the Intel i860 RISC processor. Access to the routines is via the standard C calling sequence and link-editing process. First, a call to the initialization routine, `vga_init()`, is made. Next, calls are made to other VGA library routines to perform the desired functions. Finally, a VGA cleanup routine, `vga_term()`, is called.

Housekeeping: Initialization and Termination

The VGA routines must be initialized before use. This is accomplished by calling the `vga_init()` routine and checking the `int` return value. If `vga_init()` returns a non-zero value, an error occurred while initializing the VGA. It is the user's responsibility to determine the reason for failure. Additional calls to other VGA library routines should not be made if `vga_init()` fails.

The `vga_init()` routine does basic VGA hardware initialization, in addition to setting up certain global values for programming use. VGA graphics mode HEX 13 (0x13) is selected, a default color map is loaded, the screen is cleared, and the VGA display RAM is mapped into the user's address space. VGA mode 0x13 gives the user a 320x200 pixel screen, with the 256 colors. This occupies 64000 bytes of video RAM ($320 * 200 * 8 = 64000$). Direct access to this video RAM is available; more on that later.

When VGA library functions are no longer needed in a program, a call to `vga_term()` must be made. The `vga_term()` routine essentially undoes the operations performed by `vga_init()`. That is, it returns the display to the default CGA mode 0x03 and removes the mapping of the VGA RAM from the user's address

space. Failure to call **vga_term()** before exiting from a program will leave the display in VGA graphics mode 0x13; you will not be able to get back to a Unix or DOS prompt.

A sample code fragment that initializes the VGA library might look like this:

```
main(){
    int rv;
    /* Initialize the VGA library */
    if((rv = vga_init()) != 0){
        printf("Could not initialize VGA -- error %d\n", rv);
        exit(1);
    }
    /* Insert other VGA calls here */
    /* Terminate (and reset) the VGA library */
    vga_term();
    exit(0);
}
```

VGA Library Functions

Here is a list of all currently implemented VGA library routines, along with a brief description of what each one does:

vga_init() Initializes the VGA routines. Returns zero on success.

vga_term() Terminates use of the VGA routines, and restores display to CGA mode 0x03.

vga_clear_screen() Clear the screen. That is, write zeroes to all 64000 bytes of VGA display RAM.

vga_color(c) : int c Set the color for future operations to c. c must have a value between 0 and 255 inclusive.

vga_rop(r) : int r Set the raster operation for future operations to r. r must have a value between VGA_MINROP and VGA_MAXROP (see vga.h).

vga_move(x, y): int x, y Set the position for the next drawing (or text) operation to the absolute screen coordinates (x, y). x must have a value between 0 and 319 inclusive, and y must have a value between 0 and 199 inclusive.

vga_line(x, y): int x, y Draw a line (using the current color, as set by vga_color()) from the current drawing position to (x, y). x must have a value between 0 and 319 inclusive, and y must have a value between 0 and 199 inclusive.

vga_rect(xc, yc, xl, yl): int xc, yc, xl, yl Draw a rectangle on the screen using the current color. The rectangle has its upper-left corner at (xc, yc). The width of the rectangle is xl, and the height is yl.

vga_loadfont(fn): char *fn Load X-window style font file fn into memory, and return an integer value representing the font-ID to be used for vga_setfont() calls. If there is an error loading the font file, vga_loadfont() will return a negative value. Valid font-ID's are always non-negative integers.

vga_setfont(fid): int fid Set the font for future text operations to the font specified by fid. fid was a valid font-ID returned by vga_loadfont().

vga_unloadfont(fid): int fid Disassociate the font specified by fid, and free the memory the font used. Once a font is unloaded, you can not use the font-ID again. You must explicitly reload the font using vga_loadfont(), and use the new font-ID returned.

vga_string(s, n): char *s; int n Write n characters of the string pointed to by s at the current position (as set by vga_move() or vga_line()). The font used is the one specified by the most recent vga_setfont() call. The characters are written using the current color and raster-op. The base-line of the characters writ-

ten is that of the current y position. The x position is updated to point to the end of the text just written. That is, two successive calls to `vga_string()` will cause text to be output next to each other, NOT on top of each other.

vga_fill_screen(c): int c Fill the screen with color c. This is the same as `vga_clear_screen()`, except instead of using color 0, color c is used. If you wish to fill the entire screen with a particular color, this method is preferred as opposed to `vga_rect(0, 0, 320, 200)`. `vga_fill_screen()` is an optimally coded assembler language routine, designed for speed.

Global Variables

There are several constants and global variables available to the user to make program development simpler. The first thing a programmer should do is `#include "vga.h"` in his program.

`vga.h` contains constants such as the values of the default colors, (`VGA_BLACK`, `VGA_GREEN`, ...), the raster operations, (`ROP_STORE`, `ROP_OR`, ...), the video RAM address (`VRAM`) and video RAM size (`VRAMSIZE`). Also included in `vga.h` are structure templates for color map entries and type declarations for global variables (`pos_t`, `color_t`). There are only a few global variables available to the programmer. These are listed below:

pos_t _FB_XPOS, _FB_YPOS This is the current (x, y) position. Be careful if you modify these; side-effects are unpredictable.

color_t _FB_COLOR The current color for text/draw operations.

int _FB_ROP The current raster operation as set by `vga_rop()`. The default raster operation (if you do not explicitly set one) is `ROP_STORE`.

Direct Access to Video RAM

After VGA initialization programmers may access video RAM directly by using the address defined by `VRAM` in `vga.h`. The value of `VRAM` is usually `(unsignedchar*)(0xf80a0000)`. You will notice that normal VGA RAM starts at `0xa0000`. Under APX, all you have to do is add `0xf8000000` to the VGA RAM addresses

you usually use. You can use VGA RAM like normal memory to perform various specialized tasks (like loading bitmap images, for example). A code fragment that reads a VGA bitmap file into the VGA RAM might look like this:

```
#include <stdio.h>
#include "vga.h"
main(){
    FILE *fp;
    if((fp = fopen("vga_image.dat", "r")) == NULL){
        perror("Can't open vga_image.dat");
        exit(1);
    }
    if(vga_init()){
        fprintf(stderr, "Can't initialize VGA library\n");
        exit(2);
    }
    if(fread(VRAM, 1, 64000, fp) != 64000){
        fprintf(stderr, "Could not read entire image");
        goto out;
    }
    /* At this point, the entire screen image has been
       read into VRAM */
    /* Wait for a character from the keyboard */
    getc(stdin);
out:
    fclose(fp);
    vga_term();
    exit(0);
}
```


Using the i860 Assembler, Linker and Debugger

Running the i860 Assembler

The i860 Assembler is a cross compiler that runs on the host operating system, generating linkable object code that must be run through the i860 Linker to create a program that can be executed on the i860 processor. Currently only versions of UNIX are supported as the host operating system, though the output from the i860 Linker can be run under DOS (see the paragraph entitled "Running i860 code under DOS").

The i860 Assembler is invoked by the following command:

asm860 [[[options]..]input_file]

where the brackets [and] show options, but are not used in the actual command line. The options must be separated by at least one space. Some of the options are:

-a Do not automatically import any symbols that are referenced but are otherwise undefined. Issue an error message for this case.

-be Handle all data defined in data sections in "big endian" mode (i.e. with most significant byte as lowest address).

-D sym = val Define sym as a local symbol in the macro processor with value val. The -z option must also be set.

-I inc_file Include (via the macro processor) the file inc_file before the first statement of the input_file. The -z option must also be set. To include multiple input files, use several -I statements.

-i386 Put the magic number for the 386 Architecture in the output object module instead of the magic number for the i860. This is so that i386 tools can be used to process the output from the i860 Assembler.

-I file_spec Enable a source listing. If file_spec is included after the I without any spaces, the source listing is directed to a disk file with the name file_spec. If no file_spec is named, the output will go to the standard output device.

-L Preserve text symbols that begin with .L. High level languages generate labels that begin with .L.

-m Ignore (in the assembly pass) the special directives output (in the macro pass) by the -y option.

-o output_file Set the name of the output module to output_file. If this option is not set, the i860 Assembler creates an output name of input_name.o For example, if the input file name is "hello.860" (containing i860 assembly language), if no output_file is specified, the i860 Assembler will create a file called "hello.o".

-R Suppress all .data directives; all code is assembled in the text segment, and the data segment is not used.

-x Enable additional checks of the program to find illegal sequences of instructions.

-y Output in the macro pass special directives that the assembler pass uses for better reporting of the lines in the source file where errors are detected. The -z option must also be used.

-z Use the macro processor to scan the input_file before the assembler stage. The -z option must be used for any macro processing to take place.

Running the i860 Linker

The i860 Linker is used to create a runnable i860 program from the output of the i860 Assembler. The i860 Linker puts together

modules created by the i860 Assembler (it may only be one module for a simple i860 program) and resolves inter-module symbol references to create a i860 program that can be directly executed.

The i860 Linker is executed by the following command:

ld860 [option]...[[-B** *bss_addr*] {**[-p]***input_file*}...]**

The brackets [and] show options but are not used in the actual command line, and can be any of the following:

-B *bss_addr* Specify the RAM address to be used for common blocks for the bss section of all *in_file* modules that follow. This specification can be repeated to specify different addresses for different addresses for different groups of modules. The *bss_addr* is a hexadecimal integer.

-d *integer* Specify the address at which the data section is to be loaded. The default starting address is 0x1000.

-D *integer* Specify the length of the data section as *integer* bytes. The data section is padded with NULs to the specified length. The *integer* may not be less than the original length of the data section.

-e *symbol* Specify *symbol* as the entry point of the program. The default entry point is `ls$start`.

-f *list_file* Read *list_file* for a list of i860 object modules to be linked. Names in this file can be separated by commas, spaces, tabs or newlines. Multiple **-f** statements are allowed. When the **-f** statement is used, the **-F** and **-p** options may not be used.

-i386 Use the 386 magic number instead of the i860 magic number in the output file. This will allow i386 tools to be used on the i860 Linker output.

-k Start the text and data sections exactly at the addresses

specified by the **-T** and **-d** options (or the default starting address if **-T** or **-d** options are not used) without performing the normal modifications to those addresses to make the file pageable.

-M Create a load map. If the **-M** is followed by a redirection command (**out_file**), the load map will be put into the **out_file**. Otherwise the load map will be sent to the standard output device.

-Mx Create a load map plus a cross reference.

-o output_file Put the output module in a file called **Output_file**. Otherwise use a file called: **a.out**

-p Align the data section of the following input module on a page boundary. This is useful for producing page directories and tables.

-r Retain relocation entries in **output_file**. This enables incremental linking. The **output_file** can be used as input to another i860 Linker step. When **-r** is used, the **-o** option must also be used.

-s Strip all symbols from the output file.

-t Print the name of each input file as it is processed.

-T integer Specify the address at which the text section is to be loaded. The integer is the starting address. The default starting address is **0xF0400000**.

-u symbol Initialize the symbol table with **symbol**. The i860 Linker considers **symbol** to be undefined; therefore it may be used to trigger the loading of the first member of an archive library.

-v Print the names of the input modules and libraries as they are processed.

Executing an i860 program and using the i860 Debugger

The i860 Debugger, similar in usage to the UNIX adb, will use the output from the i860 Linker, and allow the following functions:

- Setting of breakpoints in both code and data
- Reference to memory and registers via symbolic names
- Examine and set registers and memory sections
- Dissassemble i860 instructions symbolically
- Display i860 pipeline stages and call frames from the stack
- Single step i860 instructions, allowing "stepping over" procedure calls
- Debug high level language programs from source-code level.

To run the i860 Debugger, use the following command line:

```
run860 [-d][-w][-R][-r[register_type]][-l dir][[-S dir{dir}..][[-F[command_file]] object_file [parameters]
```

where:

`object_file` is the object file created by the i860 Linker, and should be executable

-d Tells the i860 Debugger to start an interactive debug session, taking requests from the keyboard. If the `-d` option is not used, `run860` simply executes the program.

-w Creates `object_file` (if necessary), and opens it for reading and writing so that this file can be modified during the debug session.

-R Instructs the i860 Debugger to display all processor registers when a batch session is terminated. This aids in comparing the

results of one debug session to a previous debug session.

-r Displays the values of specified registers when a batch session is terminated. Registers are displayed by types: f = floating point registers (single precision), d = pairs of floating point registers (double precision), i = pairs of floating point registers (64-bit integers), p = pipelines, s = simulator registers. If no type is specified, the i860 Debugger displays the integer registers and control registers.

-l directory Specifies the directory that contains files to be read with the commands \$ or \$<. The default is the current directory. No space is permitted between the -l and the directory.

-S Provides a list of directories to be used during source debugging when searching for source files. The current directory is always searched first.

-F command_file Tells the i860 Debugger to execute requests found in `command_file` when starting a debug session. This command assumes interactive debugging (the -d option must be used). The `command_file` usually contains commands to set parameters, to set standard breakpoints, and to initialize registers. If no `command_file` is specified after the -F, the i860 Debugger assumes a file named `object_file.cmd` is used.

i860 Debugger Commands

The i860 Debugger commands may use address or line expressions as part of their command line. A line number corresponds to a line from a source program file (either C or Fortran). Note that to preserve line numbers during the Compile/Assemble/Link steps, specify the -g option during compilation, and do not use the -s option during Linking, otherwise the line numbers will be stripped from the final object module used by the i860 Debugger.

The format of a command line is:

[address_exp][,count_exp] command [modifier] [;] where

the `address_exp` can be either a memory address or a line number (when doing source code level debugging), `count_exp` is used to specify the number of times the command is executed, and the modifier is dependant upon the command. In the following list of commands, the `count_exp` has not been shown, but may be used unless otherwise noted. Several debug commands can be used on the same line by separating them by the semicolon (;).

i860 processor registers

All of the registers within the i860 processor may be viewed with the `$r` command, or modified with the `command`. Please refer to the i860 Programmers Reference Manual (Intel Corp.) or the i860 Architecture Reference (McGraw Hill Publishing, author: Neil Margolis) for a listing of the i860 registers.

The format of a line number is:

`#line_number[~source_file]` where `source_file`, if not specified, is taken from the directories from the `-S` option during Debugger invocation.

`address_exp:b` Set a code breakpoint at `address_exp`

`address_exp:ba` Set breakpoint at `address_exp` after any access

`address_exp:brd` Set breakpoint at `address_exp` after read

`address_exp:brw` Set breakpoint at `address_exp` after write

`address_exp:c` Continue program execution at `address_exp`. Normally used to continue execution after a breakpoint has been reached. If `count_exp` is given, skip the next `count_exp-1` breakpoints.

`address_exp:d` Delete breakpoint at `address_exp`. If `address_exp` is not given, delete all breakpoints.

`address_exp:r [parms]` Run `object_file`. Other command line

parameters (parms) may be given after the `:r` command. The `address_exp`, if present, gives a starting location. If not present, execution starts at the standard entry point. If a `count_exp` is given, skip the next `count_exp-1` breakpoints. All program variables are reinitialized, but the breakpoints, registers and i860 Debugger variables are not changed.

`count_exp:s` Single steps `count_exp` times.

`count_exp:S` Single steps `count_exp` times, but skips over procedure calls.

`address_expname` Assign the value of `address_exp` to `name`. Name can be an i860 register or a debug register.

`address_exp /i [format]` Disassemble contents of memory starting at `address_exp`. This command can only be run after execution has been started by the `:r`, `:R`, `:s`, `:S` or `:l` commands.

Source code debug statements

`address_exp,count ?i [format]` Disassemble `count` lines of source code from `object_file` starting at `address_exp`.

`line_number:a` Display the instructions generated by the compiler at `line_number`.

`line_number:i [parms]` Single step `count_exp` source lines starting at `line_number`.

`line_number:l [parms]` Single step `count_exp` source lines but skip over procedure calls.

`line_number:w` Display the source code starting at statement `line_number`. Display `count_exp` lines.

`:n` Display the next set of source lines using the `count_exp` from the previous `:w` command.

`:p` Display the previous set of source lines using the

count_exp from the previous :w command.

Debugger restrictions

For instructions that execute in dual-instruction mode, breakpoints can be set only on the core instructions.

A breakpoint cannot be set on a delayed branch instruction.

When delayed branch instructions are used in the dual instruction mode, a breakpoint cannot be set on any of the three instructions that follow the delayed branch.

4860 Programmers Reference

This chapter is intended to aid systems programmers in writing software for, or porting software to, the Hauppauge 4860 family of MotherBoards. The Hauppauge 4860 provides PC compatible platforms with two industry standard I/O busses, the PC/AT bus (ISA) and the EISA bus.

This draft version of the system programmers reference manual focuses on describing 4860 specific features. It does not provide information on programming the industry standard MotherBoard peripherals such as timer/counters, DMA ports, etc..

I/O Port Summary (ISA/EISA)

Address	Item	Access
0F8H	Motherboard Configuration Register	Write Only
0F9H	Unused	
0FAH	Unused	
0FBH	486 Attention Interrupt	Read/Write
0FCH	860 Attention Interrupt	Write Only
0FDH	860 Configuration Register	Write Only
0FEH	860 Interrupt Controller	Read/Write
0FFH	860 Interrupt Controller Mask	Write Only

I/O Port Summary (EISA ONLY)

Address	Item	Access
C00H	Configuration RAM page register	Write Only
800H-8FFH	Configuration RAM	Read/Write
C80H-C83H	EISA ID Registers	Read Only

486 Processor Memory Map

00000000H - 03FFFFFF	Mappable as onboard DRAM, Expansion RAM, I/O bus or BIOS ROM
04000000H - BFFFFFFF	Expansion RAM, or I/O Bus
C0000000H - C1FFFFFF	Weitek 4167
C2000000H - C200FFFF	i860 I/O space
FC000000H - FFFFFFFF	Mappable as onboard DRAM, Expansion RAM, I/O Bus or BIOS ROM

Note: The state of the keyboard controller output A20 Gate will affect access to some portions of the 486's memory space.

860 Processor Memory Map

00000000H - 03FFFFFF	Mappable as onboard DRAM, Expansion Ram, I/O Bus or BIOS ROM
04000000H - BFFFFFFF	Expansion Ram, or I/O Bus
C0000000H - C1FFFFFF	Weitek 4167
C2000000H - C200FFFF	860 I/O Space
C2010000H - FBFFFFFF	Expansion Ram, or I/O Bus

FC000000H - FFFFFFFFH Mappable as onboard DRAM,
Expansion Ram, I/O Bus or
BIOS ROM

Note: The state of the keyboard controller output A20 Gate will
NOT affect the 860s memory map.

4860 Frame Buffer Memory Map

C3000000H - C303FFFF	Frame buffer memory
C2800000H - C2800018	BT431 Cursor controller
C2400000H - C2400018	BT457 DAC/Palette
C2000000H	D1 = Frame Interrupt MASK (Active LOW)
C2000008H	D0 = VSYNC (Active LOW)
C2000010H	D1 = Frame Interrupt (Active LOW)

4860 MotherBoard Configuration Register

The Motherboard configuration register is an 8 bit write only register. It is located at I/O port 0F8H and contains the following information:

Bit 0	0 = Disable Mapping RAM 1 = Enable Mapping RAM
Bit 1	0 = Disable writes to Mapping RAM 1 = Enable writes to Mapping RAM
Bit 2	0 = Select 486 cells when writing 1 = Select 860 cells when writing
Bit 3	0 = Normal Parity 1 = Force Parity Error

- Bits 4 - 5 Reserved
- Bit 6 0 = Enable Onboard Serial/Parallel Ports
 1 = Disable Onboard Serial/Parallel Ports
- Bit 7 0 = 486 External Cache Enabled
 1 = 486 External Cache Disabled

In order to allow programs to set and clear individual bits in the configuration register, a copy of the current configuration register image is stored in CMOS RAM.

Mapping RAM

The Memory Mapping RAM determines what resource each processor accesses at a given memory address:

- The Mapping RAM allows each 32K block of the first 64 Megabytes to be enabled as RAM or disabled, allowing access to off board RAM (64 bit expansion memory or I/O Bus RAM).
- In addition each block may also be marked as cacheable or noncacheable, and as read/write or read only (write protected).

The same capabilities are provided for the last 64 megabytes of memory as well.

Each processor (the 486 and the 860) has an independent memory map allowing each block of memory to be accessible to the 486, the 860, or both.

The Mapping RAM is 8K bytes, with each byte controlling access to 32K bytes of one processor's address space (4 Gigabytes of memory is mappable). Each byte in the Mapping RAM is formatted as follows:

- Bit 0 0 = Block is Read / Write
 1 = Block is Read Only (write protected)

- Bit 1 0 = Block is cacheable
 1 = Block may not be cached
- Bit 2 0 = Block is fast RAM
 1 = Block is slow RAM
- Bit 3 reserved (must be set to a 1)
- Bit 4 0 = Block has RAM enabled
 1 = Block has RAM disabled
- Bit 5 0 = Front side of SIMM Module Selected
 1 = Back side of SIMM Module Selected
- Bits 6 - 7 Bank number of SIMM module pair to select.
 for example, if Bits 6 and 7 are both 0, this selects
 SIMM Bank 0, sockets U20 and U24.

NOTE: if Bit 4 is 1 (Block does not use on board RAM), Bits 5, 6 and 7 have different definitions:

- Bit 5 RESERVED
- Bit 6 0 = Access EISA address = > 16 Megabytes
 1 = Access EISA address < 16 Megabytes
- Bit 7 0 = EISA bus
 1 = On-board EPROM select

Initial programming of the Mapping RAM is accomplished by:

- 1) Disable Interrupts
- 2) Set the Enable Writes bit and the Select 486 bit in the **4860 MotherBoard Configuration Register**
- 3) For each of the 4096 memory blocks, write that blocks' 486 control word to any memory address within the block it controls (any write to memory space while the Mapping RAM Writes are enabled will result in a write to the corresponding mapping RAM

byte)

- 4) Set the Select 860 bit in the **4860 MotherBoard Configuration Register**
- 5) For each of the 4096 memory blocks, write that blocks' 860 control word to any memory address within the block it controls
- 6) Clear the Enable Writes bit and set the Enable Mapping Ram bit in the **4860 MotherBoard Configuration Register**
- 7) Enable Interrupts

Subsequent changes to the Mapping RAM are accomplished as follows:

- 1) Disable Interrupts
- 2) Set the Enable Writes bit and set or clear the Select 486/860 bit in the configuration register
- 3) Write the block's control word to any memory address within the block it controls
- 4) Clear the Enable Writes bit in the configuration register
- 5) Enable Interrupts

Note: Any write to memory space while the Mapping RAM writes are enabled will result in a write to the mapping RAM. This includes write generated by DMA or another processor (hint: turn off DMA and interrupts when programming the Mapping RAM).

860 Processor Configuration Register

The 860 configuration register is an 8 bit write only register. It is located at I/O port 0FDH and contains the following information:

Bits 0 - 1 Arbiter Mode

Bit 1	Bit 0	Mode
0	0	Fair
0	1	Priority 486
1	0	Priority 860
1	1	Priority 64-Bit Slot

Bit 2 486 Interrupt Select

0 = Write to 486 Interrupt Register sends external interrupt 13.

1 = Write to 486 Interrupt Register sends NMI.

Bit 3:

0 = I/O Command delays inserted

1 = No I/O command delays

When enabled, 3 I/O Bus clocks (BCLKs) are inserted for 16-bit I/O devices, and 11 BCLKs are inserted for 8-bit I/O devices.

Bit 4:

0 = EISA I/O READ delayed by one BCLK

1 = No EISA I/O READ delays

Bit 5-6 Reserved

Bit 7:

0 = 860 running

1 = 860 held in reset

In order to allow programs to set and clear individual bits in the configuration register, a copy of the current configuration register image is stored in CMOS RAM.

860 Processor Interrupt Controller

When the 860 receives an interrupt it can determine the source or sources by reading the 860 pending interrupt register at I/O port 0FEH. Each bit in this register indicates a pending interrupt as follows:

Bit 0 IO system interrupt (level sensitive from

8259)

Bit 1	Timer interrupt (edge sensitive)
Bit 2	860 Attention interrupt (edge sensitive)
Bit 3	Parity interrupt (edge sensitive)
Bit 4	64-bit Expansion Slot interrupt
Bit 5	Unused
Bits 6 - 7	Reserved

Writing to I/O port 0FEH allows bits in the pending interrupt register to be selectively cleared. Writing a one to a bit in port 0FEH clears the corresponding bit in the pending interrupt register.

The 860 interrupt Mask register is a write-only register at I/O port 0FFH. This register contains a mask bit for each 860 interrupt. When an interrupt mask bit is set, no 860 interrupt is generated when the corresponding bit in the pending interrupt register is set.

Master/NON-Master EISA I/O Slots

Slots J1, J3-J6 and J8 are capable of supporting Master-mode EISA boards. Slots J2 and J7 do not support Master-Mode EISA boards.

EISA Slot Addresses

EISA slots are encoded to work in certain address ranges when used with adapter boards using AEN selection. The following address ranges apply to the slots on the 4860EISA MotherBoard:

Slot	Address Range
J1	10xx, 14xx, 18xx, 1Cxx
J2	20xx, 24xx, 28xx, 2Cxx
J3	30xx, 34xx, 38xx, 3Cxx
J4	40xx, 44xx, 48xx, 4Cxx

J5	50xx, 54xx, 58xx, 5Cxx
J6	60xx, 64xx, 68xx, 6Cxx
J7	70xx, 74xx, 78xx, 7Cxx
J8	80xx, 84xx, 88xx, 8Cxx

Keyboard Controller Input Port

Bit 0	Reserved
Bit 1	Reserved
Bit 2	0 = Turbo switch inactive 1 = Turbo switch active
Bit 3	0 = Second Level Cache present 1 = Second Level Cache not present
Bit 4	0 = Expansion RAM card present 1 = Expansion RAM card not present
Bit 5	0 = Manufacturing Test jumper installed 1 = Manufacturing Test jumper not installed
Bit 6	0 = Color monitor selected 1 = Monochrome monitor selected
Bit 7	0 = Keyboard Locked 1 = Keyboard Unlocked

486 Attention Interrupt

Writing to I/O port 0FBH generates either an 8259 interrupt 13 (AT Math Coprocessor error) or an NMI to the 486. Which interrupt is generated is selectable using the 860 Configuration Register.

When the 486 receives the interrupt it can determine the source by reading I/O port 0FBH and examining bit 0. Bit 0 equal to 1 indicates that the 486 interrupt register generated the interrupt. Reading port 0FBH causes bit 0 to be cleared following the read.

860 Attention Interrupt

Writing to I/O port 0FCH generates an 860 Attention Interrupt.

486 BIOS Special Functions

Master Processor Selection

Memory Detection & Setup

Weitek support

860 support

Setup

Ram Speed

Bus Speed

Shadow Ram

Master Processor

486/860 Ram Allocation

Internal & External Cache Control

860 BIOS Functions

Initialization

486 Detection

Master Processor Selection

POST

Setup

Ram Speed

Bus Speed

Shadow Ram

Master Processor

Internal Cache Control

486/860 Ram Allocation

Bootstrap

Heartbeat demo

UNIX386 80860 ASSEMBLER, Beta Version 2.0, 11-Apr-1989

Tue Dec 26 16:31:58 1989 Page 1

// This program, when run on a Hauppauge 4860 board with both i486 and i860
// processors, will have the i860 write alternating astericks in the upper right hand
// corner of a Hercules compatible display, while the i486 continues to run DOS. It is
// loaded from DOS with the Hauppauge utility program LOAD860.

```

1      screen_base = 0x0B0000 // Hercules screen
2      screen_offs = 160 - 8  // Place to put *
3
4      delay_count = 1000000 // Delay between *'s
5
6      iobase = 0xC2000000    // 860 I/O Space
7
8      .atmp r31
9      .text
10
11     // initialize control reg
12     // leave all ints disable
13
38200000 00000000      14      st.c    r0,psr
38800000 00000004      15      st.c    r0,fsr
30000000 00000008      16      ld.c    fir,r0
17
18     // clear pipeline
48000430 0000000c      19      pfadd.ss          f0,f0,f0
48000430 00000010      20      pfadd.ss          f0,f0,f0
48000430 00000014      21      pfadd.ss          f0,f0,f0
48000420 00000018      22      pfmul.ss f0,f0,f0
48000420 0000001c      23      pfmul.ss f0,f0,f0
48000420 00000020      24      pfmul.ss f0,f0,f0
25
edefc200e40f0000 00000024 26      mov     iobase, r15
94100001 0000002c      27      mov     0x01,r16
0de08080 00000030      28      st.b   r16, 0x80(r15) //write 01 to port 80h
29
6c000022 00000034      30      call   flush_cache // make sure we get a miss
a0000000 00000038      31      nop
32
94100002 0000003c      33      mov     0x02,r16
0de08080 00000040      34      st.b   r16, 0x80(r15) //write 02 to port 80h
35
a0020000 00000044      36      mov     r0,r2
```

```

ee5200be412000 00000048 37  mov    screen_base, r18 //set up screen
38
94100003 00000050 39  mov    0x03,r16
0de08080 00000054 40  st.b   r16, 0x80(r15) //write 03 to port 80h
41
42  loop:
43
6c00000f 00000058 44  call   delay
a0000000 0000005c 45  nop
46
9410072a 00000060 47  mov    0x072A,r16
0de08080 00000064 48  st.b   r16, 0x80(r15)
1e408098 00000068 49  st.s   r16, screen_offs(r18) // *
94100720 0000006c 50  mov    0x0720,r16
1e40809a 00000070 51  st.s   r16, screen_offs + 2(r18) //space
52
6c000008 00000074 53  call   delay
a0000000 00000078 54  nop
55
94100720 0000007c 56  mov    0x0720,r16
0de08080 00000080 57  st.b   r16, 0x80(r15)
1e408098 00000084 58  st.s   r16, screen_offs(r18) //space
9410072a 00000088 59  mov    0x072A,r16
1e40809a 0000008c 60  st.s   r16, screen_offs + 2(r18) // *
61
6bffff11 00000090 62  br     loop
a0000000 00000094 63  nop
64
65
66  delay::
9405ffff 00000098 67  mov    -1, r5
ecc6000fe4064240 0000009c 68  mov    delay_count, r6
b4c02801 000000a4 69  bla   r5, r6, delay_loop
a0000000 000000a8 70  nop
71
72  delay_loop:
b4df2fff 000000ac 73  bla   r5, r6, delay_loop
a0000000 000000b0 74  nop
75
40000800 000000b4 76  bri   r1
a0000000 000000b8 77  nop
78
79
80 //The following cache flush procedure is from the i860TM Programmer's Reference
81 //manual. Please reference this Intel manual for additional information.
82
a0000000 000000bc 83  .align .quad
84
85  flush_cache::

```

```

86
87     FLUSH_P = 0x7f000000-32
88
89     //rw = r24, rx = r25, ry = r26, rz = r27
90
91     a0220000 000000c0      91     mov     r1,r2
92     305b0000 000000c4      92     ld.c   dirbase,r27
93     e77b0800 000000c8      93     or     0x800,r27,r27
94     9419ffff 000000cc      94     adds  -1,r0,r25
95     6c000008 000000d0      95     call  D_FLUSH
96     3840d800 000000d4      96     st.c   r27,dirbase
97
98     e77b0900 000000d8      98     or     0x900,r27,r27
99     6c000005 000000dc      99     call  D_FLUSH
100    3840d800 000000e0      100    st.c   r27,dirbase
101
102    f77b0900 000000e4      102    xor    0x900,r27,r27
103    a0410000 000000e8      103    mov    r2,r1
104    40000800 000000ec      104    bri   r1
105    3840d800 000000f0      105    st.c   r27,dirbase
106
107    D_FLUSH::
108    e418ffe0 000000f4      108    or     l%FLUSH_P,r0,r24
109    ef187eff 000000f8      109    orh   h%FLUSH_P,r24,r24
110    e41a007f 000000fc      110    or     127,r0,r26
111    b740c803 00000100      111    bla   r25,r26,D_FLUSH_LOOP
112    17000021 00000104      112    ld.l  32(r24),r0
113
114    a0000000a0000000 00000108      114    .align .quad
115
116    D_FLUSH_LOOP::
117    08000000 00000110      117    ixfr  r0, f0
118    b75fcffe 00000114      118    bla   r25,r26,D_FLUSH_LOOP
119    37000021 00000118      119    flush 32(r24) + +
120    08000000 0000011c      120    ixfr  r0, f0
121
122    40000800 00000120      122    bri   r1
123    1700fe01 00000124      123    ld.l  -512(r24),r0
124
125    00000128      125    .end

```

// Program: Reset

// Sets the initial vector to jump to on the 860 processor.

```

1
2 test_addr = 0xffff000 // rom entry address
3
4 .text
5 .align .quad
6
a0000000 00000000 7 nop // two nop's for A0 errata
a0000000 00000004 8 nop
9
9401f000 00000008 10 mov test_addr, r1 // jump to test program
40000800 0000000c 11 bri r1
a0000000 00000010 12 nop
13
00000014 14 .end
```

Frame Buffer Demo

UNIX386 80860 ASSEMBLER, Beta Version 2.0, 11-Apr-1989

Fri Apr 27 14:28:32 1990 Page 1

```
// This program displays a test pattern on the Hauppauge 4860 Frame Buffer. The i860
// changes pixels in the frame buffer by writing to memory locations in the frame
// buffers memory space, which starts at location VRAM_ADDRESS.
//
// This test program will work only with version X.01 of the 64-bit frame buffer.
```

```
1
2
3     iobase = 0xC2000000    // 860 I/O Spac
4
5     // display resolution
6
7     DISPLAY_WIDTH        = 1280
8     DISPLAY_LINES       = 1024
9
10    HORIZ_STRIDE         = 2048
11
12    VRAM_ADDRESS         = 0x03000000
13    VRAM_SIZE            = 4 * 1024 * 1024
14
15    VRAM2                 = 0x03200000
16
17    //Bt457 - Brooktree Palette DAC address
18
19    PALETTE_DAC_ADDRESS  = 0x02400000
20
21    RED_ADDRESS_PORT     = 0x00
22    RED_PALETTE_RAM_PORT = 0x08
23    RED_REGISTER_PORT    = 0x10
24    RED_OVERLAY_PORT     = 0x18
25
26    GREEN_ADDRESS_PORT   = 0x20
27    GREEN_PALETTE_RAM_PORT = 0x28
28    GREEN_REGISTER_PORT  = 0x30
29    GREEN_OVERLAY_PORT   = 0x38
30
31    BLUE_ADDRESS_PORT    = 0x40
32    BLUE_PALETTE_RAM_PORT = 0x48
33    BLUE_REGISTER_PORT   = 0x50
34    BLUE_OVERLAY_PORT    = 0x58
35
```

```

36 DAC_OVERLAY_0      = 0x0
37 DAC_OVERLAY_1      = 0x1
38 DAC_OVERLAY_2      = 0x2
39 DAC_OVERLAY_3      = 0x3
40 DAC_READ_MASK_REG  = 0x4
41 DAC_BLINK_MASK_REG = 0x5
42 DAC_COMMAND_REG    = 0x6
43 DAC_CONTROL_REG    = 0x7
44
45 //      Bt431 - Brooktree Cursor chips
46
47 CURSOR = 0x02800000
48
49 CUR_ADDRESS_0_PORT = 0x00
50 CUR_ADDRESS_1_PORT = 0x08
51 CUR_RAM_PORT       = 0x10
52 CUR_CONTROL_REG_PORT = 0x18
53
54
55
56 PORTS = 0x02000000
57
58 //      Bt439 - Brooktree clock chip
59
60 Bt439_reset_port = 0x08
61
62 clk_on = 0x00000000
63 clk_off = 0x00000002
64
65 //      Frame Buffer Status Ports
66 //
67 //Read 0x00      Bit 0-Buffer Select
68 //Read 0x00      Bit 1-Frame Int. Mask
69 //
70 //Write 0x00     Bit 0-
71 //Write 0x00     Bit 1-
72 //
73 //Read 0x08      Bit 0-Vertical Sync
74 //Read 0x08      Bit 1-Clock Reset
75 //
76 //Write 0x08     Bit 0-
77 //Write 0x08     Bit 1-Clock Reset
78 //
79 //Read 0x10      Bit 0-Mouse Interrupt
80 //Read 0x10      Bit 1-Frame Interrupt
81 //
82 //Write 0x10     Bit 0 -
83 //Write 0x10     Bit 1 -
84 //

```

```

85 //Read 0x18 Bit 0 -
86 //Read 0x18 Bit 1 -
87 //
88 //Write 0x18 Bit 0-Buffer Select
89 //Write 0x18 Bit 1-Frame Interrupt Mask
90
91 FB_CLK_RST = 0x02
92 FB_VSYNC = 0x01
93
94 FB_Status_Port = 0x08
95
96 FB_CLK_RST = 0x02
97 FB_VSYNC = 0x01
98
99
100 //some colors
101
102 RED = 0b1111110000000000
103 GREEN = 0b0000001111110000
104 BLUE = 0b0000000000001111
105
106
107 .text
108
109 // Register Usage:
110 //r1 Return Address
111 //r2 Temporary
112 //r3 Unused
113 //r4 Base for accessing I/O Ports
114 //r5 Base for Frame Buffer Ports
115 //r6 Base for accessing Palette DACs
116 //r7 Base for accessing Cursor
117 //r8 Unused
118 //r9 Unused
119 //r10 Clock OFF Command
120 //r11 Unused
121 //r12 Temporary
122 //r13 Unused
123 //r14 Unused
124 //r15 Unused
125 //r16 Temporary
126 //r17 Temporary
127 //r18 Temporary
128 //r19 Video RAM address pointer
129 //r20 Unused
130 //r21 Unused
131 //r22 Used to store pixel value for RED
132 //r23 Used to store pixel value for GREEN
133 //r24 Used to store pixel value for BLUE

```

```

134 //r25 Temporary
135 //r26 Temporary
136 //r27 Temporary
137 //r28 Temporary
138 //r29 Temporary
139 //r30 Temporary
140 //r31 Temporary
141 //
142 //
143
144
145 ld$start::
146
147 // initialize control reg
148 // leave all ints disable
149
38200000 00000000 150 st.c r0,psr
38800000 00000004 151 st.c r0,fsr
30000000 00000008 152 ld.c fir,r0
153
154 // clear pipeline
155
48000430 0000000c 156 pfadd.ss f0,f0,f0
48000430 00000010 157 pfadd.ss f0,f0,f0
48000430 00000014 158 pfadd.ss f0,f0,f0
48000420 00000018 159 pfmul.ss f0,f0,f0
48000420 0000001c 160 pfmul.ss f0,f0,f0
48000420 00000020 161 pfmul.ss f0,f0,f0
162
6c0000fa 00000024 163 call fiush_cache // make sure we get a miss
a0000000 00000028 164 nop
165
eca50200e4050000 0000002c 166 mov PORTS,r5
167
ecc60240e4060000 00000034 168 mov PALETTE_DAC_ADDRESS,r6
169
ece70280e4070000 0000003c 170 mov CURSOR,r7
171
172 // reset Bt439
173
940a0002 00000044 174 mov clk_off,r10
1ca05008 00000048 175 st.s r10,Bt439_reset_port(r5)
1ca00008 0000004c 176 st.s r0,Bt439_reset_port(r5)
177
6c000056 00000050 178 call wait_for_vsync
a0000000 00000054 179 nop
180
181 //at this point vsync just became active
182

```

1ca05008 00000058	183	st.s	r10,Bt439_reset_port(r5)	
1ca00008 0000005c	184	st.s	r0,Bt439_reset_port(r5)	
	185			
6c00005c 00000060	186	call	init_palette_dacs	
a0000000 00000064	187	nop		
	188			
	189		//write some stuff to VRAM	
	190			
6c0000de 00000068	191	call	clear_screen	
a0000000 0000006c	192	nop		
	193			
94110800 00000070	194	mov	HORIZ_STRIDE,r17	
a6310001 00000074	195	shl	1,r17,r17	// pitch
ee730300e4130000 00000078	196	mov	VRAM_ADDRESS,r19	
eed60000e416fc00 00000080	197	mov	RED,r22	
941703f0 00000088	198	mov	GREEN,r23	
9418000f 0000008c	199	mov	BLUE,r24	
	200			
a2de0000 00000090	201	mov	r22,r30	// r30 = white
e3deb800 00000094	202	or	r23,r30,r30	
e3dec000 00000098	203	or	r24,r30,r30	
	204			
94120800 0000009c	205	mov	HORIZ_STRIDE,r18	
ee730300e4130000 000000a0	206	mov	VRAM_ADDRESS,r19	
	207	hline::		
1e60f000 000000a8	208	st.s	r30,0(r19)	
96730002 000000ac	209	adds	2,r19,r19	
9652ffff 000000b0	210	adds	-1,r18,r18	
525f07fc 000000b4	211	btne	r0,r18,hline	
	212			
94120800 000000b8	213	mov	HORIZ_STRIDE,r18	
ee730320e4130000 000000bc	214	mov	VRAM2,r19	
	215	hline1::		
1e60b800 000000c4	216	st.s	r23,0(r19)	
96730002 000000c8	217	adds	2,r19,r19	
9652ffff 000000cc	218	adds	-1,r18,r18	
525f07fc 000000d0	219	btne	r0,r18,hline1	
	220			
94120384 000000d4	221	mov	900,r18	
ee730300e4130000 000000d8	222	mov	VRAM_ADDRESS,r19	
a01f0000 000000e0	223	mov	r0,r31	
	224	line::		
1e60b010 000000e4	225	st.s	r22,0x10(r19)	
1e60b012 000000e8	226	st.s	r22,0x12(r19)	
1e60b014 000000ec	227	st.s	r22,0x14(r19)	
1e60b016 000000f0	228	st.s	r22,0x16(r19)	
1e60b018 000000f4	229	st.s	r22,0x18(r19)	
	230			
1e60b820 000000f8	231	st.s	r23,0x20(r19)	

1e60b822 00000fc	232	st.s	r23,0x22(r19)	
1e60b824 00000100	233	st.s	r23,0x24(r19)	
1e60b826 00000104	234	st.s	r23,0x26(r19)	
1e60b828 00000108	235	st.s	r23,0x28(r19)	
	236			
1e60c030 0000010c	237	st.s	r24,0x30(r19)	
1e60c032 00000110	238	st.s	r24,0x32(r19)	
1e60c034 00000114	239	st.s	r24,0x34(r19)	
1e60c036 00000118	240	st.s	r24,0x36(r19)	
1e60c038 0000011c	241	st.s	r24,0x38(r19)	
	242			
1e60f060 00000120	243	st.s	r30,0x60(r19)	//white line
	244	//st.s	r22,2552(r19)	//RED line
	245	//st.s	r23,2554(r19)	//GREEN line
	246	//st.s	r24,2556(r19)	//BLUE line
	247	//st.s	r30,2558(r19)	//white line
	248			
1e60f100 00000124	249	st.s	r30, 0x100(r19)	//fat white line
1e60f102 00000128	250	st.s	r30,0x102(r19)	
1e60f104 0000012c	251	st.s	r30,0x104(r19)	
1e60f106 00000130	252	st.s	r30,0x106(r19)	
1e60f108 00000134	253	st.s	r30,0x108(r19)	
1e60f10a 00000138	254	st.s	r30,0x10a(r19)	
1e60f10c 0000013c	255	st.s	r30,0x10c(r19)	
1e60f10e 00000140	256	st.s	r30,0x10e(r19)	
1e60f110 00000144	257	st.s	r30,0x110(r19)	
1e60f112 00000148	258	st.s	r30,0x112(r19)	
1e60f114 0000014c	259	st.s	r30,0x114(r19)	
	260			
1e600116 00000150	261	st.s	r0,0x116(r19)	//black line
	262			
1e60f118 00000154	263	st.s	r30,0x118(r19)	//fat white line
1e60f11a 00000158	264	st.s	r30,0x11a(r19)	
1e60f11c 0000015c	265	st.s	r30,0x11c(r19)	
1e60f11e 00000160	266	st.s	r30,0x11e(r19)	
1e60f120 00000164	267	st.s	r30,0x120(r19)	
1e60f122 00000168	268	st.s	r30,0x122(r19)	
1e60f124 0000016c	269	st.s	r30,0x124(r19)	
1e60f126 00000170	270	st.s	r30,0x126(r19)	
1e60f128 00000174	271	st.s	r30,0x128(r19)	
1e60f12a 00000178	272	st.s	r30,0x12a(r19)	
1e60f12c 0000017c	273	st.s	r30,0x12c(r19)	
	274			
a26c0000 00000180	275	mov	r19,r12	
87ff0002 00000184	276	addu	2,r31,r31	
83ec6000 00000188	277	addu	r12,r31,r12	
1d80f000 0000018c	278	st.s	r30,0(r12)	//45 deg. white line
	279			
82339800 00000190	280	addu	r19,r17,r19	//next line

	281	
8652ffff 00000194	282	addu -1,r18,r18
525f07d2 00000198	283	btne r0,r18,line
	284	
6c000047 0000019c	285	call init_cursor
a0000000 000001a0	286	nop
	287	
	288	
	289	ok::
6bffffff 000001a4	290	br ok
a0000000 000001a8	291	nop
	292	
	293	
	294	//wait_for_vsync
	295	//loop until vsync has just become active
	296	// and then return
	297	
	298	
	299	wait_for_vsync::
	300	
	301	//loop until vsync goes inactive
	302	
14bc0008 000001ac	303	ld.s FB_Status_Port(r5), r28
c79c0001 000001b0	304	and FB_VSYNC,r28, r28
73fffffd 000001b4	305	bc wait_for_vsync
a0000000 000001b8	306	nop
	307	
	308	//loop until vsync goes active
	309	
	310	no_vsync::
14bc0008 000001bc	311	ld.s FB_Status_Port(r5),r28
c79c0001 000001c0	312	and FB_VSYNC,r28,r28
7bfffffd 000001c4	313	bnc no_vsync
a0000000 000001c8	314	nop
	315	
	316	//at this point, vsync just became active
	317	
40000800 000001cc	318	bri r1
a0000000 000001d0	319	nop
	320	
	321	
	322	
	323	init_palette_dacs::
a0220000 000001d4	324	mov r1, r2
	325	
941c0004 000001d8	326	mov DAC_READ_MASK_REG, r28 //RED
0cc0e000 000001dc	327	st.b r28, RED_ADDRESS_PORT(r6)
0cc0e020 000001e0	328	st.b r28, GREEN_ADDRESS_PORT(r6)
0cc0e040 000001e4	329	st.b r28, BLUE_ADDRESS_PORT(r6)

941c00ff 000001e8	330	mov	0xff, r28
0cc0e010 000001ec	331	st.b	r28, RED_REGISTER_PORT(r6)
0cc0e030 000001f0	332	st.b	r28, GREEN_REGISTER_PORT(r6)
0cc0e050 000001f4	333	st.b	r28, BLUE_REGISTER_PORT(r6)
	334		
941c0005 000001f8	335	mov	DAC_BLINK_MASK_REG, r28
0cc0e000 000001fc	336	st.b	r28, RED_ADDRESS_PORT(r6)
0cc0e020 00000200	337	st.b	r28, GREEN_ADDRESS_PORT(r6)
0cc0e040 00000204	338	st.b	r28, BLUE_ADDRESS_PORT(r6)
0cc00010 00000208	339	st.b	r0, RED_REGISTER_PORT(r6)
0cc00030 0000020c	340	st.b	r0, GREEN_REGISTER_PORT(r6)
0cc00050 00000210	341	st.b	r0, BLUE_REGISTER_PORT(r6)
	342		
941c0006 00000214	343	mov	DAC_COMMAND_REG, r28
0cc0e000 00000218	344	st.b	r28, RED_ADDRESS_PORT(r6)
0cc0e020 0000021c	345	st.b	r28, GREEN_ADDRESS_PORT(r6)
0cc0e040 00000220	346	st.b	r28, BLUE_ADDRESS_PORT(r6)
941c0040 00000224	347	mov	0x40, r28
0cc0e010 00000228	348	st.b	r28, RED_REGISTER_PORT(r6)
0cc0e030 0000022c	349	st.b	r28, GREEN_REGISTER_PORT(r6)
0cc0e050 00000230	350	st.b	r28, BLUE_REGISTER_PORT(r6)
	351		
941c0007 00000234	352	mov	DAC_CONTROL_REG, r28
0cc0e000 00000238	353	st.b	r28, RED_ADDRESS_PORT(r6)
0cc0e020 0000023c	354	st.b	r28, GREEN_ADDRESS_PORT(r6)
0cc0e040 00000240	355	st.b	r28, BLUE_ADDRESS_PORT(r6)
0cc00010 00000244	356	st.b	r0, RED_REGISTER_PORT(r6)
0cc00030 00000248	357	st.b	r0, GREEN_REGISTER_PORT(r6)
0cc00050 0000024c	358	st.b	r0, BLUE_REGISTER_PORT(r6)
	359		
6c00000d 00000250	360	call	load_default_palette
a0000000 00000254	361	nop	
	362		
	363		//init overlay colours
0cc00000 00000258	364	st.b	r0, RED_ADDRESS_PORT(r6)
0cc00020 0000025c	365	st.b	r0, GREEN_ADDRESS_PORT(r6)
0cc00040 00000260	366	st.b	r0, BLUE_ADDRESS_PORT(r6)
	367		
ef9c0000e41cfc00 00000264	368	mov	RED, r28
0cc00010 0000026c	369	st.b	r0, RED_REGISTER_PORT(r6) //overlay 00
0cc00010 00000270	370	st.b	r0, RED_REGISTER_PORT(r6) //overlay 01
0cc00010 00000274	371	st.b	r0, RED_REGISTER_PORT(r6) //overlay 10
0cc0e010 00000278	372	st.b	r28, RED_REGISTER_PORT(r6) //overlay 11
	373		
a0410000 0000027c	374	mov	r2, r1
40000800 00000280	375	bri	r1
a0000000 00000284	376	nop	
	377		
	378		

	379	
	380	load_default_palette::
0cc00000 00000288	382	st.b r0,RED_ADDRESS_PORT(r6)
0cc00020 0000028c	383	st.b r0,GREEN_ADDRESS_PORT(r6)
0cc00040 00000290	384	st.b r0,BLUE_ADDRESS_PORT(r6)
	385	
a01c0000 00000294	386	mov r0,r28
941d0100 00000298	387	mov 256,r29
	388	next_colour::
	389	//st.b r28,RED_ADDRESS_PORT(r6)
	390	//st.b r28, GREEN_ADDRESS_PORT(r6)
	391	//st.b r28, BLUE_ADDRESS_PORT(r6)
	392	//store colour to palettes
0cc0e008 0000029c	393	st.b r28,RED_PALETTE_RAM_PORT(r6)
0cc0e028 000002a0	394	st.b r28,GREEN_PALETTE_RAM_PORT(r6)
0cc0e048 000002a4	395	st.b r28,BLUE_PALETTE_RAM_PORT(r6)
	396	
879c0001 000002a8	397	addu 1,r28,r28
539feffb 000002ac	398	btne r29, r28, next_colour
a0000000 000002b0	399	nop
	400	
40000800 000002b4	401	bri r1
a0000000 000002b8	402	nop
	403	
	404	
	405	init_cursor::
		// set addr 0 = 0
1ce00000 000002bc	406	st.s r0,CUR_ADDRESS_0_PORT(r7)
		// set addr 1 = 0
1ce00008 000002c0	407	st.s r0,CUR_ADDRESS_1_PORT(r7)
		// two command regs
94106464 000002c4	408	mov 0b0110010001100100, r16
1ce08018 000002c8	409	st.s r16,CUR_CONTROL_REG_PORT(r7)
94100000 000002cc	410	mov 0x0000,r16 // two cursor x low values
1ce08018 000002d0	411	st.s r16,CUR_CONTROL_REG_PORT(r7)
94100303 000002d4	412	mov 0x0303,r16 // two cursor x high values
1ce08018 000002d8	413	st.s r16, CUR_CONTROL_REG_PORT(r7)
94100000 000002dc	414	mov 0x0000,r16 // two cursor y low values
1ce08018 000002e0	415	st.s r16, CUR_CONTROL_REG_PORT(r7)
94100202 000002e4	416	mov 0x0202,r16 // two cursor y high values
1ce08018 000002e8	417	st.s r16, CUR_CONTROL_REG_PORT(r7)
	418	
94100000 000002ec	419	mov 0x0000,r16 // two window x low regs
1ce08018 000002f0	420	st.s r16, CUR_CONTROL_REG_PORT(r7)
94100000 000002f4	421	mov 0x0000,r16 // two window x high regs
1ce08018 000002f8	422	st.s r16, CUR_CONTROL_REG_PORT(r7)
94100000 000002fc	423	mov 0x0000,r16 // two window y low regs
1ce08018 00000300	424	st.s r16, CUR_CONTROL_REG_PORT(r7)
94100000 00000304	425	mov 0x0000,r16 // two window y high regs

```

1ce08018 00000308      426  st.s    r16,CUR_CONTROL_REG_PORT(r7)
427
ee100000e410ffff 0000030c  428  mov     0xffff,r16      // two window width low regs
1ce08018 00000314      429  st.s    r16,CUR_CONTROL_REG_PORT(r7)
94101f1f 00000318      430  mov     0x1f1f,r16     // two window width high regs
1ce08018 0000031c      431  st.s    r16,CUR_CONTROL_REG_PORT(r7)
ee100000e410ffff 00000320  432  mov     0xffff,r16     // two window height low regs
1ce08018 00000328      433  st.s    r16,CUR_CONTROL_REG_PORT(r7)
94101f1f 0000032c      434  mov     0x1f1f,r16     // two window height high regs
1ce08018 00000330      435  st.s    r16,CUR_CONTROL_REG_PORT(r7)
436
437
438  //init cursor pattern
94120200 00000334      439  mov     512,r18
ee100000e410f0f0 00000338  440  mov     0xf0f0,r16
94110f0f 00000340      441  mov     0x0f0f,r17
442  nextcurpat::
1ce08010 00000344      443  st.s    r16,CUR_RAM_PORT(r7)
1ce08810 00000348      444  st.s    r17,CUR_RAM_PORT(r7)
9652ffff 0000034c      445  adds   -1,r18,r18
525f07fc 00000350      446  btne   r0,r18,nextcurpat
447
40000800 00000354      448  bri    r1
a0000000 00000358      449  nop
450
451
452  fill_screen::
94190100 0000035c      453  mov     DISPLAY_LINES / 4,r25
ef5a0001e41a0001 00000360  454  mov     0x10001,r26
a01b0000 00000368      455  mov     r0,r27
efde0300e41e0000 0000036c  456  mov     VRAM_ADDRESS,r30
941cffff 00000374      457  adds   -1,r0,r28
458  next_line::
941d009f 00000378      459  mov     DISPLAY_WIDTH / 8 - 1,    r29
b7a0e001 0000037c      460  bla    r28,r29,fill_line
a3df0000 00000380      461  mov     r30,r31
462
463  fill_line::
1fe0d801 00000384      464  st.l   r27,0(r31)
1fe0d805 00000388      465  st.l   r27,4(r31)
1fe0d809 0000038c      466  st.l   r27,8(r31)
1fe0d80d 00000390      467  st.l   r27,12(r31)
1fe1d801 00000394      468  st.l   r27,HORIZ_STRIDE + 0(r31)
1fe1d805 00000398      469  st.l   r27,HORIZ_STRIDE + 4(r31)
1fe1d809 0000039c      470  st.l   r27,HORIZ_STRIDE + 8(r31)
1fe1d80d 000003a0      471  st.l   r27,HORIZ_STRIDE + 12(r31)
1fe2d801 000003a4      472  st.l   r27,2*HORIZ_STRIDE + 0(r31)
1fe2d805 000003a8      473  st.l   r27,2*HORIZ_STRIDE + 4(r31)
1fe2d809 000003ac      474  st.l   r27,2*HORIZ_STRIDE + 8(r31)

```

```

1fe2d80d 000003b0      475  st.l    r27,2*HORIZ_STRIDE + 12(r31)
1fe3d801 000003b4      476  st.l    r27,3*HORIZ_STRIDE + 0(r31)
1fe3d805 000003b8      477  st.l    r27,3*HORIZ_STRIDE + 4(r31)
1fe3d809 000003bc      478  st.l    r27,3*HORIZ_STRIDE + 8(r31)
1fe3d80d 000003c0      479  st.l    r27,3*HORIZ_STRIDE + 12(r31)
87ff0010 000003c4      480  addu   16,r31,r31
b7bfe7ee 000003c8      481  bla    r28,r29,fill_line
835bd800 000003cc      482  addu   r27,r26,r27
483
87de2000 000003d0      484  addu   HORIZ_STRIDE * 4,r30,r30
8739ffff 000003d4      485  addu   -1,r25,r25
533f07e7 000003d8      486  btne   r0,r25,next_line
487
40000800 000003dc      488  bri    r1
a0000000 000003e0      489  nop
490
491
492
493
494  clear_screen::
941cfff 000003e4      495  adds   -1,r0,r28
efbd0007e41dffff 000003e8      496  mov    VRAM_SIZE / 8 - 1,r29
efde02ffe41efff8 000003f0      497  mov    VRAM_ADDRESS-8,r30
b7a0e001 000003f8      498  bla    r28,r29,clear
a0000000 000003fc      499  nop
500
501  clear::
b7bfe7ff 00000400      502  bla    r28,r29,clear
2fc00009 00000404      503  fst.d  f0,8(r30) + +
504
40000800 00000408      505  bri    r1
a0000000 0000040c      506  nop
507
508
509
510 //The following cache flush procedure is from the 860TM programmer's reference
511 //manual. Please reference the manual for additional information.
512
a0220000 00000410      513  flush_cache::
514  mov    r1,r2
515
516  FLUSH_P = 0x00008000-32
517
518  //rw = r24,rx = r25,ry = r26,rz = r27
519
305b0000 00000414      520  ld.c   dirbase,r27
e77b0800 00000418      521  or     0x800,r27,r27
9419fff 0000041c      522  adds   -1,r0,r25
6c000008 00000420      523  call   D_FLUSH

```

3840d800 00000424	524	st.c	r27,dirbase
e77b0900 00000428	525	or	0x900,r27,r27
6c000005 0000042c	526	call	D_FLUSH
3840d800 00000430	527	st.c	r27,dirbase
f77b0900 00000434	528	xor	0x900,r27,r27
	529		
a0410000 00000438	530	mov	r2,r1
40000800 0000043c	531	bri	r1
3840d800 00000440	532	st.c	r27,dirbase
	533		
	534	D_FLUSH::	
e4187fe0 00000444	535	or	l%FLUSH_P, r0,r24
ef180000 00000448	536	orh	h%FLUSH_P, r24,r24
e41a007f 0000044c	537	or	127,r0,r26
171f0021 00000450	538	ld.l	32(r24),r31
a7ff0000 00000454	539	shl	0,r31,r31
b740c801 00000458	540	bla	r25,r26,D_FLUSH_LOOP
a0000000 0000045c	541	nop	
	542		
	543	.align	32
	544		
	545	D_FLUSH_LOOP::	
08000000 00000460	546	ixfr	r0,f0
b75fcffe 00000464	547	bla	r25,r26,D_FLUSH_LOOP
37000021 00000468	548	flush	32(r24) + +
08000000 0000046c	549	ixfr	r0,f0
	550		
40000800 00000470	551	bri	r1
1700fe01 00000474	552	ld.l	-512(r24),r0
	553		
a0000000 00000478	554	nop	
a0000000 0000047c	555	nop	
a0000000 00000480	556	nop	
a0000000 00000484	557	nop	
	558		
00000488	559	.end	